

INSTRUCTION MANUAL

HCH-1T Hydraulic Engine Crane - Euro Style 1T



A357

A357

5-3-13

1000KG HCH-1T EURO SHOP CRANE

INSTRUCTION MANUAL



NOTE: Owner/Operator must read and understand this instruction manual before using the crane

Specifications

Model	SA500	SA1000
Capacity (kg)	500	1000
Base width(outside) (mm)	950	950
Base width(inside) (mm)	800	800
Max.Boom Length (mm)	1360	1360
Min.Boom Length (mm)	1060	1060
Max.Hook Height (mm)	2225	2225
Min.Hook Height (mm)	470	470
Net Weight (kg)	86	103

Safety Instructions

1. Use cranes only on a firm level; never use on soft grounds.
2. The load to be lifted should never exceed the rated capacity.
3. Never operate the hydraulic power unit beyond its maximum stroke indicated on the label.
4. The capacity of the crane reduces as the jib extension is prolonged. Do not load the crane beyond the rated capacity for each specified jib extension position as indicated in the label.
5. The load hook is provided with a latching mechanism. Ensure it works properly.
6. To lift the load in a well balanced and stable way make sure the center of gravity remains always inside the crane base.
7. Never position any part of your body under the load.
8. Do not allow the load to swing or drop violently when moving.
9. The crane is not transportation device but in case the load has to be removed, lower the load and jib extension to the lowest

possible point before transporting. The crane is not designed to sustain the load indefinitely, so when the operation is finished make sure the load is fully lowered and supported on a firm surface.

10. Make a visual inspection before each use the crane. Any crane which appears to be damaged must be removed from service.
11. As an additional safety feature the crane is equipped with a valve to prevent the unit from being overloaded. This unit must not be tampered with.
12. If these basic rules are not followed, injury to the user, the crane or the load being lifted may result.

Use and operation

1. Before using the crane, it is necessary to purge air from the valve system of the hydraulic unit.
2. This can be done by releasing the valve ,then pumping the hydraulic jack several times.
3. Closing the valve, the crane is now ready to be used. Swival the hydraulic unit a suitable operating position.
4. Raising the load, close the valve and pump the hydraulic unit. Any manipulation of the pressure relief valve is prohibited.
5. Lowering the load, release the valve slowly, the load can be lowered smoothly. Quick-releasing is strictly prohibited.

Maintenance

1. Lubricate all moving parts at regular intervals.

2. Always keep the crane clean and protected from aggressive conditions.
3. Check the oil level of the hydraulic unit with the piston fully retracted. Top up if necessary.

IMPORTANT : An excess of oil will render the crane inoperative.

4. Use only hydraulic oil, HL or HM types, with an ISO grade of cinematic viscosity of 30 cSt at 40° C or an Engler viscosity of 3 at 50° C.

VERY IMPORTANT : never use brake fluid.

5. When ordering spare parts, please state the part number as shown in the exploded view drawing provided, the model number and the capacity of the crane.

REPAIR

Both maintenance and repair must only be carried out by qualified personnel.

Please follow positioning and orientation of parts as per factory Assembly drawing supplied, using details below as reference.

When putting nuts and bolts together on Lifting equipment, it is a good practice to put bolt up from underneath and nut on top.

This way if nut comes loose, bolt falls out and it will be noticed missing .

If put with bolt from top and the nut falls off, the bolt stays where it is and is not noticed as a problem as readily.

With Base (#5) upside down, fit wheels (#4) with axle (#3) still in wheel into slots provided at end of legs.

Tighten nuts ensuring when tightening axle does not come up in groove.

Fit the Swivel wheels (#6) as shown into cross member, noting the 2 large washers (#7) stay on the wheel shaft!!

The Bolt with Lock Washer and smaller washer come in from the other side. Tighten as best you can now (To be tightened later)




Turn Base over onto its wheels and fit Post (#58) assembled as is, shown below



Note nut, Spring Washer , Flat Washer on top of M12 x 85 long Bolt

Do not tighten yet!



Fit support arms (#16) to base loosely then attach at post (#58) with bolts supplied M10 x 80mm long bolts
Tighten top bolts then bottom ones of Supports then the 4 holding Post (#58) to base (#5)




With Weight of machine on wheels, you should now be able to **tighten the bolts holding swivel wheels on.**




Fit Handle #27

#Fit the Boom and lifting arm assembly ensuring Circlips are Repositioned correctly in groove of pins.

And 2 x Spacers for Ram pin are placed one each side of ram.




Re-Check all fasteners are TIGHT



Parts List

No	Description	Qt'y	No	Description	Qt'y
1	Nut	7	2	Washer	16
3	Pin	2	4	Front wheel	2
5	Base	1	6	Steering wheel	2
7	Washer	4	8	Screw	4
9	Nut	4	10	Spring Washer	4
11	Washer	10	12	Screw	4
13	Washer	2	14	Spring Washer	2
15	Screw	2	16	Support	2

17	Screw	1	18	Washer	2
19	Nut	1	20	Screw	1
21	Screw	2	22	Snap ring	4
23	Pin	1	24	Socket	1
25	Jack handle	1	26	Hand grip	3
27	Handle	1	28	Washer	2
29	Screw	2	30	Spring seat	1
31	Washer	2	32	Screw	2
33	Boom	1	34	Pin	1
35	Spring pin	1	36	Lifting arm	1
37	Nut	1	38	Screw	1
39	Washer	1	40	Pin	1
41	Nut	1	42	Hook seat	1
43	Hook bolt	1	44	Spring	1
45	Ball	12	46	Screw	1
47	Hook	1	48	Latch	1
49	Spring	1	50	Pin	1
51	Ram assembly	1	52	Spacer	2
53	Linkage	1	54	Pin	1
55	Pin	1	56	Pin	1
57	Snap ring	4	58	Post	1



Parts List (Ram assembly)

No	Description	Qt'y	No	Description	Qt'y
101	Cylinder Head	1	102*	O-Ring	1
103*	Square-Ring	2	104	Reservoir	1
105*	Oil Plug	1	106	Piston Rod	1
107*	O-Ring Retaining	1	108*	O-Ring	1
109	Cylinder	1	110*	Washer	1
111	Screw	1	112*	Washer	1
113	Spring	1	114	Ball	1
115	Ball	2	116	Screw	1
117*	Washer	1	118	Screw	1
119	Spring	1	120	Seat	1
121	Ball	1	122*	O-Ring	1
123*	Scraper Ring	1	124*	Snap Ring	1
125	Pump	1	126	Valve Block	1
127*	O-Ring	1	128	Release Indicator	1
129	Spring	1	130	Screw	1
131	Release Knob	1			
*Included in the repair kit					

VERSION TWO