











128-080602-R0

PARTS LIST
MODEL NO. 128

CODE NO	PART NO	DESCRIPTION	SPECIFICATION	QTY	NOTE
1	S022	Hex. Head Screw	5/16X3/4	4	
2	N003	Hexagon Nut	1/4"	1	
3	W004	Washer	1/4"x19xt1.5	1	
4S2	3004FS	Stand Complete Assembly		1	
4-1	3004F-1	Cross Brace		2	
4-2	3004F-2	Stand Leg		4	
4-3	3004F-3	Leg		2	
4-4	3004F-4	Leg		2	
4-5	3206	Screw	5/16"x3/4"L	16	
4-6	W016	Washer	5/16"x23xt2	16	
4-7	N007	Hex. Nut	5/16"	16	
4-8	S017	Hex. Head Screw	5/16"x1"L	6	
4-9	W016	Washer	5/16"x23xt2	12	
4-10	N007	Hex. Nut	5/16"	6	
4-11	32421E-3	Coaster of Stand	3/8"	4	
6	N007	Hex. Nut	5/16"	4	
15S	3015S	Adjust Tension Rod		1	
16	E158412	Motor Cable		1	
17	3017	Pivoting Rod		1	
18	W205	Spring Washer	5/16"	2	
19	3019	Distance Set Bracket		1	
20	S018	Hex. Head Screw	5/16"x5/16"L	1	
21	3021	Stock Stop Rod	ϕ1/2"x216L	1	
22	3022-1	Wire Relief Retainer		2	
27	S017	Hex. Head Screw	5/16"x1"L	2	
28	3028B	Hand wheel		1	
30	HE013	E Retaining Ring	E10	1	
31	S017	Hex. Head Screw	5/16"x1"L	1	
32S	3032S	Lead Screw		1	
32-1	3032	Lead Screw		1	
32-2	3033	Vise Nut		1	
34	3034	Movable Vise Plate		1	
35	W011	Washer	3/8"x27xt3	4	
36	S013	Hex. Head Screw	3/8"x1-1/4"L	1	
37	3037A	Swivel Base		1	
38	S708	Cross Round Head Screw	3/16"x3/8"L	2	
39	3039B	Scale		1	
40	S708	Cross Round Head Screw	3/16"X3/8L	1	
41	HI107	Wire Ring	3/8"	1	
43	3043	Wire protector		1	
44	195314	Power cable		1	
45	3045	Spring Handle Bracket		1	
45-1	3045-1	Spring Handle Bracket		1	
46	3046	Spring Adjusting Screw		1	
47	3047	Spring		1	
49	3049	Movable Vise Plate		1	
50	S022	Hex. Head Screw	5/16"x3/4"L	4	
51	W018	Washer	5/16"x23xt3	3	

PARTS LIST
MODEL NO. 128

CODE NO	PART NO	DESCRIPTION	SPECIFICATION	QTY	NOT
52	S019	Hex. Head Screw	5/16"x1-1/2"L	1	
53	S001	Hex. Head Screw	7/16"x2"L	1	FOR CE ON
54	3054B	Pivot		1	
55S	3055AS	Vertical Saw Table (Optional)		1	FOR NON C
55-1	S301	Flat Cross Head Screw	1/4"x3/8"L	1	FOR NON C
55-2	3055A	Vertical Saw Table (Optional)		1	FOR NON C
55-3	3056-2	Table Supporting Plate		1	FOR NON C
55-4	N003	Hexagon nut	1/4"	1	FOR NON C
58	3058	Plum handle Screw		1	
59	3059B	Blade Back Safety Cover		1	
59-1	W004	Washer	1/4"×19×t1.5	2	
59-2	S704	Cross Round Head Screw	1/4"×3/8"L	2	
61	S610	Hex.Socket Headless Screw	5/16"x5/16"L	1	
63S1	3064SA1	Blade Adjustable Assembly (Rear)		1	
63-1	3064	Blade Adjustable (Rear)		1	
63-2	3062	Bearing Shaft		1	
63-3	3062-1	Guide Pivot (Right)		1	
63-4	C100	C-Retainer Ring		2	
63-5	CA6000ZZ	Bearing	6000ZZ	3	
63-6	3063	Bearing Pin	φ10x36L	1	
63-7	N006	Hex. Nut	3/8"UNF	2	
63-8	W204	Spring Washer	φ3/8"	2	
63-9	3069	Deflector Plate		1	
63-10	S302	Flat Cross Head Screw	1/4"x3/8"L	2	
63-11	32405	Adjustable Bracket (Right)		1	
63-12	S023	Hex. Head Screw	5/16"x1-1/4"L	1	
63-13	W205	Spring Washer	φ5/16"	1	
63-14	W016	Washer	5/16"x23xt2	1	
64S1	3064SB1	Adjustable Bracket Assembly (Right)		1	
64-1	3064-1	Blade Adjustable (Front)		1	
64-2	3062	Bearing Shaft		1	
64-3	3062-1	Guide Pivot (Left)		1	
64-4	HCS01	C-Retainer Ring		2	
64-5	CA6000ZZ	Bearing	6000ZZ	3	
64-6	3063	Bearing Pin	φ10x36L	1	
64-7	N006	Hex. Nut	3/8"UNF	2	
64-8	W204	Spring Washer	φ3/8"	2	
64-9	32406	Adjustable Bracket (Left)		1	
64-10	S023	Hex. Head Screw	5/16"x1-1/4"L	1	
64-11	W205	Spring Washer	φ5/16"	1	
64-12	W016	Washer	5/16"x23xt2	1	
66	3066-3	Blade Adjustable Knob	3/8"-16UNCx31L	1	
67	W205	Spring Washer	5/16"	2	
69	S013	Hex. Head Screw	3/8"x1-1/4"L	1	
71	3071	Blade Wheel (Front)		1	
71-1	S610	Hex. Socker Headless Screw	5/16"x5/16"L	1	
72	3072-2	Bearing Cover		2	
73	HK109	Key	5x5x25L	1	

PARTS LIST
MODEL NO. 128

CODE NO	PART NO	DESCRIPTION	SPECIFICATION	QTY	NOTE
74	HK109	Key	5x5x30L	1	
75	S202	Hex. Head Screw	1/4"x5/8"L	4	
76S2	3076-2S	Switch Cut Off Tip(For CE Only)		1	FOR CE ONLY
76-1	3076-2	Switch Cut Off Tip(For CE Only)		1	FOR CE ONLY
76-2	N007	Hex. Nut	5/16"	1	FOR CE ONLY
76-3	S017	Hex. Head Screw	5/16"x1"L	1	FOR CE ONLY
76-4	S203	Hex. Head Screw	1/4"x3/8"L	1	FOR CE ONLY
76-5	W004	Washer	1/4"×16t×1.5	1	FOR CE ONLY
76S3	3076S	Switch Cut Off Tip(For CE Only)		1	
76-1	3076	Switch Cut Off Tip		1	
76-2	W004	Washer	1/4"x16xt1.5	1	
76-3	S202	Hex. Head Screw	1/4"x5/8"L	1	
77S2	3077S-1	Blade Wheel Assembly (Rear)		1	
77-1	3077-1	Blade Wheel (Rear)		1	
77-2S	3106S	Blade Wheel Shaft Assembly		1	
	3106	Sliding Plate Draw Block		1	
	HP013	Pin	ψ4*20L	1	
77-5	3119-1	Blade Wheel Bushing		1	
77-6	CA6202ZZ	Ball Bearing (6202ZZ)	6202ZZ	2	
77-7	3126	Bushing		1	
79	3079E	Blade tension adjustable knob	3/8"-16UNCx105L	1	
80	3080	Spring		1	
81	3081D	Body Frame		1	
83	S002	Hex. Head Screw	1/2"x1-1/2"L	2	
84	3084-1	Motor Mount Plate		1	
85		Motor		1	
85-1	ET2906	Wire Guard	Y2	3	
86	3086A	Motor Pulley		1	
86-1	S644	Hex. Socker Headless Screw	5/16"x1/4"L	1	
89	3089	Oil Seal	TC15x35x7	1	
90S	3091JS	Transmission Gear Assembly		1	
90-1	3090	Transmission Wheel Shaft		1	
90-2	3091J	Transmission Gear		1	
90-3	P005	Pin	φ4x22L	1	
90-4	HK109	Key	5x5x25L	1	
90-5	CA6202ZZ	Ball Bearing (6202ZZ)	6202ZZ	2	
90-6	3088	Bushing		1	
90-7	3089	Oil Seal	TC15x35x7	1	
91	N007	Hex. Nut	5/16"	2	
92	3092	Gear Box Gasket		1	
93	3093	Gear Box Cover		1	
94S1	3094S-1	Worm Gear Shaft Assembly		1	
94-1	3094-1	Worm Gear Shaft		1	
94-2	CA6202ZZ	Ball Bearing (6202ZZ)	6202ZZ	2	
94-3	3096-1	Bearing Bushing		1	
98	3098	Plum Screw	5/16"-18UNCx45L	1	

PARTS LIST
MODEL NO. 128

CODE NO	PART NO	DESCRIPTION	SPECIFICATION	QTY	NOTE
98	S019	Hex. Head Screw	5/16"x1-1/2"L	1	FOR CE ONLY
99	W016	Washer	5/16"x23xt2	8	
100	S304	Flat head cross screw	5/32"x3/8"L	6	
101	3101-2A	Worm Gear Pulley		1	
101-1	S611	Hex. Socket Headless Screw	5/16"x5/8"L	1	
103S	3103S	Blade Tension Sliding Plate Assembly		1	
103-1	3108	Shaft Block		1	
103-2	3103	Blade Tension Sliding Plate		1	
103-3	S603	Hex. Socket Headless screw	5/16"x3/4"L	1	
103-4	W018	Washer	5/16"x23xt3	1	
103-5	S023	Hex. Head Screw	5/16"x1-1/4"L	1	
104	S017	Hex. Head Screw	5/16"x1"L	1	
109	3109	Blade Tension Sliding Guides		2	
111	110110	Motor Pulley Cover Assembly		1	
112	3112B	Belt		1	
113		Blade	0.65x12.7x1638Lx14T	1	
116	W004	Washer	1/4"x19xt1.5	2	
118	S006	Hex. Head Screw	1/4"x1/2"L	2	
120	3120	Bushing	Ø9x Ø7x7	2	
122	N010	Hexagon nut	7/16"	1	FOR CE ONLY
123	S052	Hex. Head Screw	1/4"x1"L	1	
132	3132	Safety Guard (Right)		1	
133	3132-1	Safety Guard (Left)		1	FOR CE ONLY
134	S711	Cross Round Head Screw	5/32"x1/4"L	2	FOR CE ONLY
155	N004	Hex. Nut	3/16"	1	FOR CE ONLY
156	S708	Cross Round Head Screw	3/16"X3/8"L	1	
157	W302	Star Washer	3/16"	2	
158	W004	Washer	1/4"x16xt1.5mm	1	
159	3058	Plum handle Screw	3/16"x1/2"L	1	
187	W018	Washer	5/16"x23xt3mm	1	
188	N007	Hex. Nut	5/16"	1	
189	W018	Washer	5/16"x23xt3	1	
197	S009	Hex. Head Screw	1/4"x3/4"L	1	FOR CE ONLY
198	HCS04	C-Retainer ring	S15	1	
199	N003	Hexagon nut	1/4"	1	FOR CE ONLY
203S	ET1401S	Toggle Switch	2P	1	
203-1	ET1401	Toggle Switch	2P	1	
203-2	3131B	Switch Cover		1	
203-3		Switch Indicator		1	
203-4	3131A-2	Hex. Head Screw		2	
203-6	S732	Cross Round Head Screw	3/16"x3/4"L	2	
203-7	3041-1	Electric Cord Clip		1	
207	32312	Position pin		1	
208	32310	Plum handle		1	
209	3172	Fixed Plste		1	
210	S402	Hex. Socket Head Screw	1/4"x1/2"L	1	
211	S204	Hex. Head Screw	1/4"x3/4"L	1	

PARTS LIST
MODEL NO. 128

CODE NO	PART NO	DESCRIPTION	SPECIFICATION	QTY	NOTE
211-1	W015	Washer	5/16"x12xt2	1	
212	S017	Hex. Head Screw	5/16"x1"L	2	
214	S202	Hex. Head Screw	1/4"x5/8"L	4	
215	HB812	Net	1/4"	1	
224S2	3193DS	Switch Base		1	FOR CE ONLY
224-1	S202	Cross Socker Hex. Head Screw	1/4"x3/8"L	2	FOR CE ONLY
224-2	W202	Star Washer	3/16"	2	FOR CE ONLY
224-3	3193D	Switch Base		1	FOR CE ONLY
224-4	32408C	Switch Base		1	FOR CE ONLY
224-5	HS514	Cross Round Head Screw	M4x35L	1	FOR CE ONLY
226S		Push Switch		1	FOR CE ONLY

MACHINERYHOUSE