


INSTRUCTION MANUAL

SIEG X3

Mill Drill - Geared Head (240V)

(X) 400mm (Y) 150mm (Z) 350mm

Dovetail Column



M153

IMPORATANT SAFETY INSTRUCTION

READ ALL INSTRUCTIONS AND WARNINGS BEFORE USING THIS TOOL

Operator

PLEASE REMEMBER:

1. When using electric tools, machines or equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury.
2. Keep work area clean. Cluttered areas invite injuries.
3. Consider work area conditions. Do not use machines or power tools in damp, wet, or poorly lit locations. Do not expose equipment to rain, keep work area well lit. Do not use tools in the presence of flam-mable gases or liquids.
4. Keep children away, all children should be kept away from the work area.
5. Guard against electric shock. Prevent body contact with grounded surfaces such as pipes, radiators, ranges, and refrigerator enclosures.
6. Stay alert. Never operate if you are tired.
Do not operate the product if under the influence of alcohol or drugs. Read warning labels on prescriptions to determine if your judgment or reflexes might be impaired.
8. Do not wear loose clothing or jewelry as they can be caught in moving parts.
9. Wear restrictive hair covering to contain long hair.
10. Use eye and ear protection. Always wear.
11. Keep proper footing and balance at all times.
12. Do not reach over or across running machines.

Before operations

1. Be sure the switch is OFF when not in use and before plugging in.
2. Do not attempt to use inappropriate attachments in an attempt to exceed the tool's capacity. Approved accessories are available from the dealer or machine maker.
3. Check for damaged parts, before using any tool, any part that appears damaged should be carefully checked to determine that it will operate properly and perform its intended function. Check for alignment and binding of all moving parts, broken parts or mounting fixtures and any other condition that may affect proper operation. Any part that is damaged should be prop early repaired or replaced by a qualified technician.
5. Do not use the tool if any switch does not turn off and properly

Operation

1. Never force the tool or attachment to do the work of a larger industrial tool. It is designed to do the job better and more safely at the rate for which it was intended.
2. Do not carry the tool by its power cord.
3. Always unplug the cord by the plug. Never yank the cord out of the wall.
4. Always turn off the machine before unplugging.

IF THERE IS ANY QUESTION ABOUT A CONDITION BEING SAFE OR UNSAFE, DO NOT OPERATE THE TOOL!

Grounding Instructions

This machine has a three prong plug, the third prong is the ground. Plug this cord only into a three-prong receptacle. Do not attempt to defeat the protection the ground wire provides by cutting off the round prong. Cutting off the ground will result in a safety hazard and void the warranty.

DO NOT MODIFY THE PLUG IN ANY WAY. IF YOU HAVE ANY DOUBT, CALL A QUALIFIED ELECTRICIAN.


Specifications

Drilling capacity	25 mm
End mill capacity	25 mm
Face mill capacity	50 mm
Max spindle stroke	80 mm
Throat	232 mm
Max distance spindle to table	250 mm
Spindle taper	MT#3
Spindle speed	High range Low range
	100- 2000 rpm \pm 10% 100- 1000 rpm \pm 10%
T-slot size	12 mm
Table effective size	550 x 160 mm
Table longitudinal travel	400 mm
Table cross travel	160 mm
Motor output power	600W
Weight (net/gross)	135 kg/ 160kg

Unpacking & Preparing for use

Before unpacking you must check the package carefully, to find whether it is damaged, if it's damaged and may have effect on the machine, please connect with the distributor in advance.

Unpacking carefully, check the species of standard accessories and the quantity to find whether it is as same as the packing list in the package.



1	Cover of column	11	Worktable
2	High/Low speed change lever	12	Spindle
3	Vertical slide	13	Handle for spindle moving
4	Column	14	Handle for spindle locking
5	Base	15	Dust cover (optional accessory)
6	Adjustable screw	16	Cover of spindle
7	Longitudinal feed hand wheel	17	Cover of headstock
8	Lifting hand wheel	18	Motor
9	Cross feed hand wheel	19	Fixed plate of motor
10	Saddler	20	Cover of motor

Installation

CAUTION!

DO NOT ATTEMPT TO USE THE MACHINE UNTIL INSTALLTION IS COMPLETED, AND ALL PRELIMINARY CHECKS HAVE BEEN MADE IN ACCORDANCE WITH THIS MANUAL.

MOUNTING THE MACHINE

The machine should be mounted on a strong, heavy workbench, of sufficient height so that you do not need to bend your back to perform normal operations.

Ensure the location is adequately lit and that you will not be working in your own shadow.

We strongly recommend that the machine bolted firmly to a strong workbench using the tapped holes used to secure the feet to the machine. This is to provide added stability and consequently, additional safety.

To do this, first drill four M12 clearance holes in a worktop, at the dimensions shown in the diagram opposite, and with appropriate length M12 bolts, or screws, with flat washers. (not supply)




Fig 2

Starting procedure

INITIAL START (ref. Fig.3)

1. Taking all precautions previously stated, set the High-Low range lever to LOW.
2. Select FORWARD, use the Forward/Off/Reverse (F/O/R) switch (F).
3. Release the Emergency Stop switch (E) by rotating its cover clockwise, the cover should jump out automatically.
4. Set the Main Power switch(G) to 1, at the mean time the Power Indicating lamp(B) will light (green). If the Fault Indicating lamp(C) lights (yellow) too, Switch off the Variable Speed control knob(D) .
5. Switch on the machine by GENTLY turning the Variable Speed control knob(D), clockwise. A click will be heard as power is turn on, but the spindle will not rotate until the knob is turned clockwise a little further, Speed will increase progressively the further the knob is turned.
6. Run for a total of five minutes during which time gradually increase spindle speed to its maximum.

Run for at least two minutes at this speed before stopping the machine and disconnecting from the mains supply.

7. Check that all components are still secure and working freely and correctly.
Check also to ensure the mountings are secure.
Repeat the procedure at the HIGH range setting.




Fig 3

A – Fuse box B – Power indicating lamp C - Fault Indicating lamp
D – Variable speed control knob E – Emergency stop switch F – Forward/Off/Reverse
switch G– Main power switch H – Cooling fan I– Power cord w/plug

CAUTION!

NEVER attempt to change from HIGH to LOW range with the machine running.

OVER-LOAD protection(ref. Fig.3)

When the feeding speed is too fast, or the strength you press is too big, that will cause the machine beyond its capacity, machine would stop automatically for safety, at this time, the Fault Indicating lamp(C) lights (yellow). If you want to start again, just switch off the Variable Speed control knob(D) then switch it on. The machine will start again.

Wedge adjustment

When the machine has operated for a long time, you should adjust the wedge of the worktable and the position of the saddle.

The needed adjusted position of the wedge, e.g.

1. The cross wedge between the worktable and the saddle.
2. The longitudinal wedge between the saddle and the base.

The way of the adjustment is, adjusting the screws of wedge till the handle moving smoothly, then tighten the nuts for locking these screws.

Maintenance

For maximum performance, it is essential that the machine is properly maintained.

Before use

Always inspect before use. Any damage should be repaired and maladjustment rectified. Damage to machined surfaces should be repaired with an oil stone. Test by hand to ensure smooth operation of all parts before use.

Inject a few drops of oil to the oilways at bearings and once or twice during the day if used continuously

After use

Remove all swarf from the machine and thoroughly clean all surfaces. Worktable should be dry, and all machined surfaces should be lightly oiled. Always remove drill bits, cutting tools, and store in a safe place.


Motor brush


The motor brushes could be changed by unscrewing the caps, visible at the top of the motor.


No	Description	Qty	No	Description	Qty
1	Transmission gear	1	43	Clockwork spring	1
2	Dial fork	1	44	Adjust washer	1
3	Small gear rack	1	45	Left support flange	1
4	key block	2	46	Pinion	1
5	Protecting flange of spindle	1	47	Right support flange	1
6	Under oil seal I	1	48	Big dial	1
7	Spindle	1	49	Big handle seat	1
8	Sleeve limit pad	1	50	Washer	1
9	Under oil seal II	1	51	Dial fork shaft	1
10	Spindle sleeve	1	52	Handle shank	3
11	Spindle box	1	53	Move shaft	1
12	Draw Bar	1	54	Adjust washer	1
13	Washer I	1	55	Right support flange	1
14	Washer II	1	56	Adjust washer	1
15	Inside spline sleeve	1	57	Rotate handle	1
16	Square bearing seat	1	58	Spindle lock sleeve II	1
17	Spindle out gear	1	59	Spindle lock handle	1
18	Spindle box cover	1	60	Spindle lock sleeve I	1
19	Adjustment pad	1	61	Washer	1
20	Protecting pad of spindle	1	62	Small handle	1
21	Bearing seat	1	63	Adjust Screw	1
22	Flange	1	64	Wedge	1
23	II shaft	1	65	Verticality table	1
24	Washer of II shaft	1	66	End cap	1
25	Transmission gear	1	67	Washer	1
26	Washer	1	68	Slanting shaft	1
27	I shaft	1	69	Small handle	3
28	Up press loop	1	70	Pressing spring	3
29	Big Timing belt	1	71	Spring piece	4
30	Under press loop	1	72	Bearing 8106	1
31	Bearing seat	1	73	Bearing 80107	1
32	Washer	2	74	Bearing 80101	4
33	Center finding shaft	1	75	Timing belt	1
34	Side cover of spindle box	1	76	oil cup 6	7
35	Move gear	1	77	Oil cup 8	1
36	Washer	1	78	Steel ball 5	3
37	Motor fixed tray	1	79	Bearing Z007106	1
38	Motor encloser	1	80	Bearing 80106	1
39	Under press loop	1	81	Screw M5*20	8
40	Motor pulley	1	82	Screw M5*40	5
41	Up press loop	1	83	Pin 6*25	2
42	Spring encloser	1	84	Key 4*40	2

85	Screw M4*16	2	128	Screw M4*20	4
86	Pin 4*16	1	129	Verticality lead rail	1
87	Screw M6*16	1	130	Side plate II	1
88	Nut M6	11	131	Side plate I	1
89	Screw M5*12	6	132	Screw thread shaft	2
90	Pin 4*8	1	133	Limit sleeve	1
91	Screw M6*8	1	134	Under bearing seat	1
92	Screw M6*12	1	135	Verticality lead screw	1
93	Small round nut M27*1.5	2	136	Verticality leadscrew nut	1
94	Check ring 62	1	137	Support	1
95	Check ring 35	1	138	Up Bearing seat	1
96	Washer 12	1	139	Back canopy hood	1
97	Nut M12	1	140	Cover board I	1
98	Key 8*20	1	141	Cover board II	1
99	Key 4*25	2	142	Screw M6*10	1
100	Key 5*40	2	143	Screw M5*8	2
101	Screw M4*16	2	144	Washer 10	4
102	Spring 4	2	145	Screw M8*20	4
103	Key 4*16	6	146	Pin 8*45	2
104	Screw M4*8	6	147	Screw M5*8	2
105	Check ring	2	148	Screw M4*5	10
106	Screw M5*16	3	149	Bolt M10*50	4
107	Screw M4*8	4	150	Pin 4*20	12
108	Check ring 10	1	151	Pin 4*26	1
109	Key 3*16	1	152	Pin 6*30	2
110	Screw M6*16	4	153	Ruler	1
111	Screw M4*6	4	154	Cushioning cylinder	1
112	Check ring	6	155	Bearing 8101	8
113	Pin 3*10	1	156	Bearing 80101	1
114	Check ring 16	1	157	Adjust screw	4
115	Pin 4*16	1	158	Base	1
116	Screw M4*16	7	159	Saddle	1
117	Screw M6*16	5	160	Worktable	1
118	Screw M5*16	23	161	Washer	2
119	Washer 5	8	162	Y-axis feeding screw	1
120	Pin 4*10	1	163	X-axis screw nut	1
121	Long handle sleeve	3	164	Y-axis screw nut	1
122	Screw M6*6	1	165	X-axis wedge	1
123	Screw M10*25	4	166	Y-axis bearing seat	1
124	Key 4*12	1	167	Gear	2
125	Pin 5*10	1	168	Sleeve	1
126	Pin 6*26	2	169	Rotate shaft	1
127	Screw M5*6	1	170	Support flange	1


171	X-axis feeding screw	1	213	Lead tube	2
172	Y-axis wedge	1	214	Switch label	1
173	X-axis bearing seat	1	215	Fuse box	1
174	Nut M12	4	216	Power indicating Lamp	1
175	Hand wheel	2	217	Potentiometer with Switch	1
176	Nut M8	6	218	Emergency stop Switch	1
177	Hand wheel	1	219	Reverse/Off/Forward Switch	1
178	Finger	1	220	PC Board	1
179	Handle sleeve	3	221	Screw M4*35	4
180	Inlay ring	3	222	Cooling fan	1
181	Dial	3	223	Power cord	1
182	Screw M8*55	3	224	Motor	1
183	Screw M4*12	4	225	Fault indicating lamp	1
184	Screw M6*25	8	226	Power switch	1
185	Washer 8	3	227	Nut M4	4
186	Pin 3*20	4			
187	Screw M6*6	1			
188	Rivet 2*3	2			
189	Cap nut	3			
190	Splash guard	1			
191	Lead rail rotate body	1			
192	Small rotate shaft	1			
193	Thick washer	1			
194	Protective cover lead rail	1			
195	Support Bracket	1			
196	Caution label	1			
197	Motor lable	1			
198	Main label	1			
199	Lock Label	1			
200	Inlay strip	1			
201	Spring	1			
202	Screw M6*6	1			
203	Pin 3*18	1			
204	Screw M5*10	4			
205	Washer 6	1			
206	Screw M4*5	1			
207	Inlay strip 8*3*200	1			
208	Fine lead wire 1*85	1			
209	Microswitch	1			
210	Microswitch Protective cover	1			
211	Screw M3*10	2			
212	Lead tube connect	4			







MACHINERYHOUSE



Packing List

No.	Name	Description	Q'ty
1	Drill chuck with key	13 mm	1
2	Double end wrench	8*10, 14*17, 17*19	Each 1
3	L Hex. Wrench	S: 3, 4, 5, 6	Each 1
4	Oil can		1
5	Draw bar		1
6	Taper shank	MT#3	1
7	Nut	M12	1
8	Washer	12mm	1
9	T-nut		2
10	Oblique wedge		

PLANT SAFETY PROGRAM

NEW MACHINERY HAZARD IDENTIFICATION, ASSESSMENT & CONTROL

Stock Code: M153

Description: Milling Machine

Model: X3 3mt

Brand: HAFCO

Developed in Co-operation Between A.W.I.S.A and Australia Chamber of Manufactures
 This program is based upon the Australian Worksafe Standard for Plant(NOHS:1010-1994)




Item No.	Hazard Identification	Hazard Assessment	Risk Control Strategies (Recommended for Purchase / Buyer / User)
A	ENTANGLEMENT	HIGH	Eliminate, avoid loose clothing / Long hair etc.
B	CRUSHING	LOW	Secure & support workpiece on mill table.
C	CUTTING, STABBING, PUNCTURING	MEDIUM	Isolate power to machine prior to any checks or maintenance being carried out. Do not adjust or clean machine until the machine has fully stopped.
D	SHEARING	MEDIUM	Make sure all guards are secured shut when machine is on. Isolate power to machine prior to any checks or maintenance.
F	STRIKING	MEDIUM	Ensure tooling is secure in chuck. Wear safety glasses. Stand clear of moving parts on machine. Remove all loose objects around moving parts. Ensure correct spindle direction when milling.
H	ELECTRICAL	MEDIUM	All electrical enclosures should only be opened with a tool that is not to be kept with the machine. Machine should be installed & checked by a Licensed Electrician.
M	HIGH TEMPERATURE	LOW	Wear appropriate protective clothing to prevent hot swarf.
O	OTHER HAZARDS, NOISE.	LOW	Wear hearing protection as required.

Plant Safety Program to be read in conjunction with manufactures instructions



ABN 96 000 286 957

"THE JUNCTION" 2 WINDSOR ROAD, NORTHMEAD NSW 2152
 Phone (02) 9890 9111 Fax (02) 9890 3888

Authorised and signed by: 
 Safety officer: 
 Manager: 

Date: Mar-02