

HAFCO WOODMASTER

THICKNESSER OPERATION MANUAL



Models

T-380, T-380S, T-20, T-20A, T-20S

Order Code W414, W414S, W415, W415A, W415S

Edition No : TH-002

Date of Issue : 07/2019

www.machineryhouse.com.au

MACHINE DETAILS

| | |
|----------------------|--|
| MACHINE | <input type="text" value="THICKNESSER"/> |
| MODEL NO. | <input type="text"/> |
| SERIAL NO. | <input type="text"/> |
| DATE OF MANF. | <input type="text"/> |

Distributed by



www.machineryhouse.com.au

www.machineryhouse.co.nz

NOTE:

This manual is only for your reference. Owing to the continuous improvement of the HAFCO machines, changes may be made at any time without obligation or notice. Please ensure the local voltage is the same as listed on the specification plate before operating this electric machine.



NOTE:

In order to see the type and model of the machine, please see the specification plate. Usually found on the back of the machine. See example (Fig.1)

HAFCO
PRODUCT SPECIFICATION

MODEL:

CAPACITY:

SER. NO.:

MFG DATE:

WEIGHT:

VOLTS:

MOTOR Kw:

www.machineryhouse.com.au
Made in China

Fig.1

OPERATION MANUAL

CONTENTS:

| | |
|---|----|
| 1. GENERAL MACHINE INFORMATION | |
| 1.1. Specifications..... | 4 |
| 1.2 Identification T-380..... | 5 |
| Identification T-20..... | 6 |
| Identification Drive Rollers & Cutter Head..... | 7 |
| 2. IMPORTANT INFORMATION | |
| 2.1 General Machinery Safety | 8 |
| 2.2 Additional Safety For Thicknessers..... | 11 |
| 2.3 Lifting Instructions..... | 13 |
| 3. INSTALLATION | |
| 3.1 Base Foundation and Securing Points..... | 13 |
| Placement Location..... | 13 |
| Leveling..... | 13 |
| 3.2 Setting Up. Attachments..... | 15 |
| Attaching the Support Rollers..... | 15 |
| Attaching the Handwheel..... | 15 |
| Attaching the Dust Hood..... | 15 |
| Dust Extraction..... | 16 |
| 3.3 Connecting To The Power Supply..... | 16 |
| 3.4 Test Run..... | 17 |
| 4. OPERATION | |
| 4.1. Basic Controls..... | 17 |
| Operation Overview..... | 18 |
| Operating Tips..... | 19 |
| Feed Rate..... | 19 |
| Depth of Cut..... | 20 |
| Bed Rollers Height..... | 20 |
| 5. MAINTAINANCE | |
| 5.1 Lubrication..... | 21 |
| Feed Roller Bushings..... | 21 |
| Table Height Worm Gear..... | 21 |
| Column and Leadscrews..... | 21 |
| Drive Sprockets and Chain..... | 22 |
| Table Height Sprockets and Chain..... | 22 |
| Gear Box Oil..... | 22 |
| 5.2 Troubleshooting..... | 23 |
| 6. ADJUSTMENTS | |
| 6.1 Replacing Cutter Blades..... | 25 |
| 6.2 Replacing Insert Type Cutters..... | 26 |
| 6.2 Tensioning and Replacing Drive Belts..... | 27 |
| 6.3 Adjusting Height Of In-feed Roller, Chlpbreaker, Pressure Bar & Out-feed Roller..... | 28 |
| 6.4 Adjusting Kickback Fingers..... | 29 |
| 6.5 Positioning The Chip Deflector..... | 29 |
| 6.6 Setting Digital Readout..... | 30 |
| Spare Parts..... | 31 |

OPERATION MANUAL

1.1 SPECIFICATIONS

| ORDER CODE | W414 | W414S | W415 | W415A | W415S |
|--|-----------------------|--------------------------|-----------------------|-----------------------|-------------------------|
| MODEL | T-380 | T-380S | T-20 | T-20A | T-20S |
| Material Width Capacity (mm) | 380 | 380 | 508 | 508 | 508 |
| Max. Stock Thickness (mm) | 150 | 150 | 200 | 200 | 200 |
| Minimum Material Length (mm) | 175 | 175 | 190 | 190 | 190 |
| Maximum Depth of Cut At Full Width (mm) | 2 | 2 | 6 | 6 | 6 |
| Cutter Type | HSS Blades - Straight | Carbide Inserts - Spiral | HSS Blades - Straight | HSS Blades - Straight | Carbide Inserts - Spira |
| Quantity of Cutters | 3 x Blades | 68 x Insert | 4 x Blades | 4 x Blades | 92 x Inserts |
| Cutter Block Diameter (mm) | 73 | 73 | 80 | 80 | 80 |
| Cutter Block Speed (R.P.M) | 5000 | 5000 | 5000 | 5000 | 5000 |
| Quantity of Spirals | ~ | 4 | ~ | ~ | 4 |
| Length of Table (mm) | 520 | 520 | 650 | 650 | 650 |
| Length of Table with Extensions/Rollers (mm) | 1015 | 1015 | 1470 | 1470 | 1470 |
| Feed Speed (M/Min) | 4.8 / 6 | 4.8 / 6 | 4.8 / 6 | 4.8 / 6 | 4.8 / 6 |
| Dust Outlet Diameter (mm) | 100 | 100 | 125 | 125 | 125 |
| Motor Power (kW / HP) | 1.5 / 2 | 2.2 / 3 | 3.75 / 5 | 2.25 / 3 | 3.75 / 5 |
| Power Requirement | 240V, 50Hz, 1Ph | 240V, 50Hz, 1Ph | 415V, 50Hz, 3Ph | 240V, 50Hz, 1Ph | 415V, 50Hz, 3Ph |
| Full-Load Current Rating (Amps) | 12.5 | 14 | 8 | 18 | 8 |
| Minimum Circuit Size (Amps) | 15 | 15 | 10 | 20 | 10 |
| Floor Space (W x D x H) | 770 x 1015 x 1100 | 820 x 1015 x 1100 | 1000 x 1470 x 1030 | 1000 x 1470 x 1030 | 1000 x 1470 x 1030 |
| Shipping Dimensions (L x W x H) | 760 x 630 x 780 | 760 x 630 x 780 | 750 x 950 x 1100 | 750 x 950 x 1100 | 750 x 950 x 1100 |
| Nett Weight (Kgs.) | 230 | 230 | 420 | 420 | 420 |


1.2 IDENTIFICATION T-380

Fig. 1

| | | | |
|----------|----------------------|----------|------------------------|
| A | Head Casting | I | Base |
| B | Return Rollers | J | Stand |
| C | Dust Chute | K | Lifting Handles |
| D | Gearbox Cover | L | ON/OFF Switch |
| E | Hand Wheel | M | Table Extension Roller |
| F | Gear Shift Handle | N | Locking Clamp |
| G | Digital Height Gauge | O | Column |
| H | Working Table | P | Table Rollers |



1.2 IDENTIFICATION T-20 Series

Fig. 2

| | | | |
|----------|----------------------|----------|------------------------|
| A | Head Casting | I | Base |
| B | Return Rollers | J | Stand |
| C | Dust Chute | K | Lifting Handles |
| D | Gearbox Cover | L | ON/OFF Switch |
| E | Hand Wheel | M | Table Extension Roller |
| F | Gear Shift Handle | N | Locking Clamp |
| G | Digital Height Gauge | O | Column |
| H | Working Table | P | Table Rollers |

1.2 IDENTIFICATION Drive Rollers and Cutter Head

- A.** Anti-Kickback Fingers: Provide additional safety for the operator.
- B.** Serrated Infeed Roller: Pulls the workpiece toward the cutterhead.
- C.** Chip Breaker: Breaks off chips created by the cutterhead to prevent tearout and diverts the chips to the dust port.
- D.** Chip Deflector: Directs chips into the dust hood.
- E.** Cutterhead: Holds the cutter blades that remove material from the workpiece.
- F.** Pressure Bar: Stabilizes the workpiece as it leaves the cutterhead and assists in deflecting wood particles toward the dust hood.
- G.** Outfeed Roller: Pulls the workpiece through the thicknesser.
- H.** Table Rollers: Provide a rolling surface to enable the feed rollers to pull the workpiece along.
- I.** Table: Provides a smooth and level path for the workpiece as it moves through the thicknesser.

2. IMPORTANT INFORMATION

2.1 General Machine Safety

INSTRUCTION MANUAL.

Read and understand this instruction manual BEFORE using the machine. Store the manual in a safe place for future reference.

ENVIRONMENTS.

Do not use any machinery in areas that are cluttered, wet, or has poor lighting. Operating machinery in these areas greatly increases the risk of accidents and injury.

TRAINED OPERATORS.

A higher risk of being hurt or killed can occur with untrained operators.

Only trained or supervised people should use the machine. Disconnect the power, or remove the switch keys, to prevent the machine's unauthorized use, when the machine is not being used. Children must not operate this machine.

ALERTNESS.

Never operate under the influence of drugs or alcohol, when tired, or when distracted. Mental alertness is required for the safe operation of machinery.

ELECTRICAL INJURY RISKS.

Operators can be shocked, burned, or killed by touching live electrical components or improperly grounded machinery. To reduce this risk, only allow a qualified electrician or service personnel to do electrical installation or repair work, and always disconnect power before accessing or exposing electrical equipment.

DISCONNECT POWER .

Always disconnect the machine from the power supply BEFORE making adjustments, changing tooling, or servicing the machine. This prevents an injury risk from unintended start-up or contact with live electrical components.

EYE PROTECTION.

Always wear AS/NZ-1336 approved safety glasses or a face shield when operating or observing machinery to reduce the risk of eye injury or blindness from flying particles. Everyday eyeglasses are NOT approved safety glasses.

HEARING PROTECTION.

Extended exposure to this noise without hearing protection can cause permanent hearing loss. Always wear hearing protection when operating or observing loud machinery.

2.1 General Machine Safety

PROPER CLOTHING.

Do not wear clothing, or jewelry that can become entangled in moving parts. Always tie back or cover long hair. Wear non-slip footwear to reduce the risk of slipping and losing control which could cause accidentally contact with the cutting tool or moving parts.

HAZARDOUS DUST.

Some dust created by machinery operations may be hazardous to your long-term health. Always wear a safety approved respirator to reduce the risk to your health. Be aware of dust hazards associated with each workpiece material.

CHILDREN & BYSTANDERS.

Children and bystanders must be kept at a safe distance from the work area. Stop using the machine if they become a distraction.

OPERATING POSITIONS.

Avoid awkward hand positions that make the workpiece control difficult or increase the risk of accidental injury. Keep proper footing and balance at all times when operating the machine.

KEEPING THE WORK AREA CLEAR.

Never leave chuck keys, wrenches, or any other tools on the machine. Always verify that the work area is clear before starting! Tools left on machinery can become dangerous projectiles upon startup.

GUARDS & COVERS.

Guards and covers reduce accidental contact with moving parts or flying debris. Make sure they are properly installed, undamaged, and working correctly BEFORE operating the machine.

USING THE CORRECT TOOL.

Only use the tool for its intended purpose. Do not force the tool or an attachment to do a job for which it was not designed. Never make unapproved modifications. Modifying the tool or using it for a purpose that it was not intended for may result in malfunction or mechanical failure that can lead to personal injury or death!

FORCING MACHINERY.

Do not force the machine. It will do the job safer and better at the rate for which it was designed.

NEVER STAND ON THE MACHINE.

Serious injury may occur if the cutting tool is contacted or the machine is tipped.

OPERATION MANUAL

2.1 General Machine Safety

MAKING THE MACHINE STABLE.

Before starting, verify the machine is stable and the mobile base (if used) is locked. Unexpected movement during operation greatly increases risk of injury or loss of control.

USE RECOMMENDED ACCESSORIES.

Check with the distributor or the manufacturer for recommended accessories. Using improper accessories could increase the risk of serious injury.

UNATTENDED OPERATION.

Turn the machine OFF and ensure all moving parts are completely stopped before walking away. This will reduce the risk of accidental injury. Never leave the machine running while unattended.

MAINTAINENCE.

Follow all the lubrication schedules and maintenance instructions to keep the machine in good working condition. A machine that is improperly maintained could malfunction, and cause serious personal injury or death.

DAMAGED PARTS.

Regularly inspect the machine for damaged, loose, or mis-aligned parts. Check for any condition that could affect the safe operation. Immediately repair or replace BEFORE operating the machine. For your own safety, DO NOT operate the machine with damaged parts!

MAINTAIN POWER CORDS.

When removing the cords connected to the machine from the power supply, grab and pull the plug—NOT the cord. Pulling the cord may damage the wires inside. Do not handle the cord or plug with wet hands. Avoid cord damage by keeping it away from heated surfaces, high traffic areas, and wet or damp locations.

EXPERIENCING DIFFICULTIES.

If at any time you are experiencing difficulties performing the intended operation, stop using the machine, and contact your local distributor for technical support



2.2 Additional Safety for Thicknessers

OWNER'S MANUAL.

This machine presents significant safety hazards to untrained users. Read and understand this entire manual before starting the thicknesser.

KICKBACK.

DO NOT operate this thicknesser until you have a clear understanding of kickback and how it occurs. Kickback happens when the workpiece is thrown back towards the operator by the cutters. The operator needs to have a clear understanding of kickback before the machine is operated.

REACHING INSIDE THICKNESSER.

Never reach inside the thicknesser while it is connected to power. Serious personal injury from the cutterhead can occur. Never operate the machine with the guards removed.

BODY PLACEMENT.

To avoid getting hit if a kickback occurs, always stand to one side of the thicknesser during the entire operation.

LOOKING INSIDE THICKNESSER.

Wood chips fly around inside the thicknesser at a high rate of speed during operation. To avoid injury from flying material, DO NOT look inside the thicknesser during operation.

USING CORRECT MATERIAL.

Only machine natural wood stock with this thicknesser. DO NOT machine MDF, plywood, laminates or other synthetic materials that can break up inside the machine and cause injury hazards.

GRAIN DIRECTION.

Machining across the grain is hard on the thicknesser and may cause kickback. Always machine in the same direction or at a slight angle with the wood grain.

CLEAN STOCK.

Machining stock with nails, staples, or loose knots may cause debris to be thrown at the operator at a high rate of speed and will damage the cutterhead. To avoid these hazards, always thoroughly inspect and prepare the workpieces.

CLEARING JAMS.

To avoid serious personal injury from the spinning cutterhead, always stop the thicknesser and disconnect it from power before removing a jammed workpiece.

2.2 Additional Safety for Thicknessers

INFEED AND OUTFEED ROLLER CLEARANCE.


The infeed and outfeed rollers are designed to feed material into and away from the spinning cutterhead, and doing so clamps the material firmly to the base. To avoid serious personal injury, always keep hands, clothing, jewellery, and long hair away from the infeed and outfeed rollers during operation.

DISCONNECT BEFORE ADJUSTMENTS.

To avoid unexpected start-up and serious personal injury, always disconnect the thicknesser from the power before performing adjustments, maintenance, or service.

PINCH POINTS

Beware of pinch points that can cause serious damage to fingers and hands especially around the support rollers on the out feed. (Fig.2.1) It is best practice to wait for the workpiece to stop feeding before removing.



OPERATION MANUAL

2.3 Lifting Instructions

The thicknessers in this manual are heavy. Serious personal injury could occur if safe moving methods are not used. Get assistance and use the correct lifting equipment to move the shipping crate and when removing the machine from the crate.

NOTE: Check the weight of the machine on the specification plate before lifting the machine and only use approved lifting slings.

Lifting

The cabinet stand on your thicknesser is equipped with four lifting bars that pull out in order to lift the machine. Once the machine is in place the handles can be pushed back into the casting. Make sure that machine is kept in a level position while lifting, (Fig. 2.2)




Fig. 2.2

3. INSTALLATION

3.1 Base Foundation and Leveling

Check the weight and footprint specifications of your machine. Some residential floors may require additional reinforcement to support both the machine and operator. Hafco recommends that for best results the machine should be placed on a cement reinforced floor with a minimum thickness of 150mm.

Placement Location


Consider the existing and all anticipated needs, the size of the material to be processed through the machine, and extra space for auxiliary stands, work tables or other machinery when picking a location for the machine. See Fig. 3.1 on Page 14 for the minimum working clearances.

Leveling

With the machine in position, test the table surface lengthwise and crosswise with machinist level. Place metal shims under the low corners until the machine is level. Check that all four corners are supported, and the machine does not rock, then tighten the hold down bolts, retest the level of the table surface in both directions; and adjust again if necessary.

3.1 Base Foundation and Leveling Cont.

Model T-380



Model T-20




Fig. 3.1

3.2 SETTING UP ATTACHMENTS

Attach the Support Rollers

Attach the table extension rollers to the thicknesser table with the hex bolts, lock washers, and flat washers, but do not fully tighten the bolts at this time.

Using a straightedge as a guide, position the support rollers evenly with the table, then fully tighten the hex bolts. (Fig. 3.2)

Note: Do not rest the straightedge on the table rollers which would give you a false reading.



Fig. 3.2

Attach The Hand Wheel

Place the bushing on the hand wheel shaft and insert the key into the shaft keyway. Slide the hand wheel on the shaft and secure it with the hex nut and flat washer, as shown in Figure 3.3



Fig. 3.3

Attach The Dust Hood

Attach the dust hood to the top of the thicknesser with the 3 hex bolts, flat washers, and hex nuts as shown in Figure 3.4, then attach the bottom of the dust hood to the thicknesser with the cap screws.

Note: You will need to reach into the dust hood to hold the hex nuts while tightening the hex bolts.



Fig. 3.4

OPERATION MANUAL
Dust Extraction

DO NOT operate these thicknessers without an adequate dust collection system. This thicknesser creates substantial amounts of wood dust while operating. Failure to use a dust collection system could result in short and long-term respiratory illness. HAFCO recommends that a Dust Extractor with a minimum of 680 C.F.M.

Fit the hose to the dust hood and clamp. (Fig.3.5)




Fig. 3.5

3.3 CONNECTING TO THE POWER SUPPLY:

The electric motor, switch, and cord are supplied with the Thicknessers. If a plug is fitted, the plug must be plugged into a matching outlet that is properly installed and grounded in accordance with the local electrical codes. The power cord must have a earth pin.

You **MUST** connect your machine to a grounded circuit that is rated for the amperage given below. Never replace a circuit breaker on an existing circuit with one of higher amperage without consulting a qualified electrician. Never replace a plug with a plug of lower amperage.

| Model | T-380A | T-380S | T-20 | T-20 | T-20S |
|--------------------------|------------|------------|------------|------------|------------|
| Power Required | 240V 50 Hz | 240V 50 Hz | 415V 50 Hz | 240V 50 Hz | 415V 50 Hz |
| Amps Required | 15 | 15 | 15 | 20 | 15 |
| Full Load Current | 12.5 | 14 | 8 | 18 | 8 |


WARNING

Improper connection of the motor can result in a risk of electrical shock.

If it is necessary to use an extension lead, the lead should be grounded and be able to carry the correct amperage. Use a short lead length, to avoid power loss and over-heating.

All electrical work must be carried out by a qualified electrician.

IMPORTANT: An extension lead should only be used as an interim solution until the machine can be plugged directly into the socket. For best protection, if possible use a surge-protected plug outlet.

NOTE:

Electrocution or fire could result if the machine is not grounded and installed in compliance with electrical codes. Compliance **MUST** be verified by a qualified electrician!.

OPERATION MANUAL

3.4 Test Run

Before starting the test run it is important that you make sure there is oil in the gearbox before proceeding. To check the oil, remove the gearbox cover, then remove the gearbox fill plug. (Fig. 3.6)

Using the short end of a clean hex key, dip it inside the fill hole and then remove it.

If the end of the hex wrench is coated with oil, then the gearbox oil level is okay.

Replace the fill plug.

If the end of the hex key is not coated with oil, then oil needs to be added. Refer to the gearbox filling instructions on Page 22




Fig. 3.6

Fill Plug

Once the oil level has been checked, test run your machine to make sure it runs properly and is ready for operation. Before you start the machine make sure you understand the safety instructions in the manual and that the machine has been set up correctly.

NOTE: Make sure all tools and objects used during the setup have been cleared away from the machine.

Start the machine and verify that [1] The motor powers up and runs correctly and [2] the safety stop button safety works correctly.

If, during the test run, there is an unusual noise or vibration, stop using the machine straight away and locate the source of the noise or vibration. If unsuccessful consult the Troubleshooting section on Page 23

4. OPERATION

4.1 Basic Controls.

The following descriptions will help you to become familiar with the basic controls of your machine. (Refer Fig. 4.1 on page 18)

- A. Magnetic ON/OFF Switch:** Starts/stops the Thicknesser.
- B. Return Rollers:** Provide a convenient method for returning the workpiece to the infeed side of the Thicknesser.
- C. Table Height Handwheel:** Controls the elevation of the table under the cutterhead.
- D. Feed Rate Control Knob:** Switches the feed rollers between high and low feed rates or, in the center position, stops the feed rollers.
- E. Table Locks:** Locks the table in position so it does not move during operations.
- F. Digital Height Gauge:** Displays the height movements and position.


HAFCO WOODMASTER
OPERATION MANUAL


Fig. 4.1

Operation Overview

This section gives you the basic process that happens during an operation with this machine. Familiarize yourself with this process to better understand the remaining parts of the Operation section.

To complete a typical operation, the operator should do the following:

1. First check that the workpiece is clean and free of any defects or foreign materials that might cause kickback or damage the cutters.
2. Adjusts the height of the table for the correct depth of cut.
3. Start the dust collection system.
4. Connect the thicknesser to the power supply and turn the machine ON.
5. Move the Feed Rate Control Lever (Fig. 4.1) to the correct position
5. The operator should place their body to the side of the machine, then lay the workpiece on the infeed table and feed it into the machine until the infeed roller engages it and moves it past the cutterhead.
6. When the workpiece exits the thicknesser, return it to the infeed table, using the return rollers and make as many passes as necessary.
7. When finished turn the machine OFF.

Operating Tips

- ❑ Where ever possible use the full width of the thicknesser cutters. If the width is smaller than the width of the cutters, alternate the cutting path between the left, the right and the middle of the table to evenly distribute the wear across the cutters.
- ❑ Scrape all glue off joined boards before putting the timber through the thicknesser
- ❑ ONLY machine natural wood. Do not machine wood composites or any other man-made material.
- ❑ Machine the workpiece with the grain. NEVER feed end-cut or end-grained lumber into your machine.
- ❑ Keep the work area clear.
- ❑ Always true up any cupped or warped stock on a jointer or bandsaw before placing it through the thicknesser.
- ❑ When making multiple passes through the thicknesser with long stock, use the stock return rollers on top of the machine to move the material back to the infeed side.
- ❑ When possible, machine both faces of the workpiece so that they will be parallel with one another

Feed Rate

The infeed and outfeed rollers move the workpiece through the thicknesser while keeping it flat and providing a consistent rate of movement.

Use the two feed rates as stated below:

- Low Feed Rate.....Roughing Pass
- High Feed Rate.....Finishing Pass

The three different positions of the feed rate control knob are as follows.:

- Push the knob in to use the high feed rate
 - T-380 20 fpm
 - T-20 20 fpm
- Pull the knob out to use the low feed rate of
 - T-380 16 fpm
 - T-20 16 fpm
- Move the knob to the center position to place the gearbox in neutral.




Fig. 4.2

Depth of Cut

The depth of cut on the thicknesser is controlled by using the handwheel on the right side of the machine. Rotating the handwheel clockwise raises the table.

The depth of cut can be read directly from the inch/millimeter scale on the R/H side column of the machine and from the digital display. One turn of the handwheel raises or lowers the table approximately 1.6mm. The thicknesser can machine material with a thickness of 6-150mm (T-380) 6-200mm (T-20). The correct depth of cut varies according to wood hardness and the workpiece width. HAFCO recommends a maximum depth of cut of no more than 1.6mm each pass. Light cuts will give a better result and put less stress on the planer.




Fig. 4.3

Bed Roller Height

The table rollers are set to the height for general machining, when the machine leaves the factory and most operators will not need to adjust them on their machines. However, the height of the table rollers may vary, for different types of material being machined. The normal range for the table roller height is 0.05–0.5mm above the table surface. (Fig. 4.4)

When machining rough timber, set the rollers high to keep the timber from dragging across the table. When machining milled timber, set the rollers low.




Fig. 4.4

To adjust the table rollers:

1. DISCONNECT THICKNESSER FROM THE POWER!
2. Lower the table to the bottom position
3. Loosen the set screws above each of the four roller adjustment hex bolts, two on each side (Fig. 4.5).
4. Using a straight edge and feeler gauge, rotate the eccentric adjustment hex bolts to raise or lower the bed rollers until they are the desired height above the table surface.
5. Verify that both sides of each roller are at the same height, then re-tighten the four set screws to secure the setting.




Fig. 4.5

5. MAINTENANCE

5.1 Lubrication

The thicknesser is supplied with bearings that are lubricated and sealed at the factory. These bearing do not require any further attention unless they need to be replaced. If a bearing fails, the thicknesser will probably develop a noticeable rumble or vibration, which will increase when the machine is under load. The bearings are standard sizes and can be replaced.

Feed Roller Bushings

The infeed and outfeed rollers rotate inside bushing blocks on both ends of the rollers. Add 2–3 drops of SAE 30W oil to the center hole of the four feed roller tension adjustment bolts on top of the head casting. (Fig. 5.1)





Table Height Worm Gear


Remove the three cap screws that secure the worm gear housing (see Fig. 5.2), then lift the housing and handwheel assembly off the machine. Clean away any debris from the housing and gears, then brush on a moderate amount of multi-purpose grease to the gear teeth.



Columns and Leadscrews (T-380)

The table is supported and moves on the columns by the rotation of the leadscrews inside the columns. (Fig. 5.3)

Apply a thin coat of SAE 30W oil to the outside surface of the columns and brush on a light application of multi-purpose grease to the leadscrew threads. Move the table up and down to distribute the lubricant.



T-20 Columns & Leacrews

Slide the cover up and apply a thin coat of SAE 30W oil to the outside surface of the columns and brush on a light application of multi-purpose grease to the leadscrew threads. Move the table up and down to distribute the lubricant. Move the cover down to protect the machine surfaces.

Drive Sprockets and Chain

The infeed and outfeed rollers are powered through the drive chain from the cutterhead on the right hand side of the machine. (Fig. 5.4) Remove the table height handwheel and the safety covers attached to the outside of the drive chain cover, then remove the cover to access these parts.

Use a clean rags to wipe away any debris and grime, then brush on a light coat of SAE 30W oil to the chain and sprockets.




Fig. 5.4

Table Height Sprockets and Chain.

The column leadscrews, responsible for the table lift, are synchronized by a chain and sprockets setup located underneath the base of the thicknesser.(Fig. 5.5) To access these parts, remove the front and rear cabinet panels. Use a clean rag to wipe away any debris and grime, then brush on a light coating of SAE 30W oil to the chain and sprockets.




Fig. 5.5

Gearbox Oil

The gearbox oil should be changed after the first 20 hours of operation to clear away any debris inside the gearbox, then changed yearly thereafter. To fill the gearbox oil, remove the drive chain cover. Once removed the drain and the fill plugs will be able to be accessed.




Fig. 5.7

Fill Plug




Fig. 5.6

Drain Plug

Drain the oil from the gearbox by removing the drain plug (Fig.5.6)

Replace the gearbox oil with 80W–90W gear oil until it just reaches the fill plug. (Fig. 5.7)

OPERATION MANUAL

5.2 Troubleshooting

Should any problems arise review the troubleshooting procedures in this section to find the possible problem or fix and adjust your machine.

For spare parts view the procedure for ordering as layed out on the first page of spare parts section.

| Symptom | Possible Cause | Possible Solution |
|---|--|---|
| Machine does not start or a breaker trips. | <ol style="list-style-type: none"> 1. Stop push-button engaged/faulty. 2. Power switched OFF or at fault. 3. Thermal overload relay has tripped. 4. Wall circuit breaker tripped. 5. Plug/receptacle at fault/wired incorrectly. 6. Motor connection wired incorrectly. 7. Contactor not energized. 8. Wiring open/has high resistance. 9. ON/OFF switch at fault. 10. Start capacitor at fault. 11. Centrifugal switch at fault 12. Motor at fault. | <ol style="list-style-type: none"> 1. Check magnetic switch/replace it. 2. Ensure power supply is switched ON 3. Reset trip load dial if necessary; replace. 4. Ensure circuit size is correct/replace. 5. Test for good contacts; correct the wiring. 6. Correct motor wiring connections 7. Test all legs for power/replace if faulty. 8. Check and fix broken, disconnected wires 9. Replace switch. 10. Test/replace if faulty. 11. Adjust/replace centrifugal switch. 12. Test/repair/replace. |
| Machine stalls or is underpowered | <ol style="list-style-type: none"> 1. Feed rate too fast. 2. Workpiece material not suitable. 3. Dust collection ducting problem. 4. Motor overheated. 5. V-belt(s) slipping. 6. Run capacitor at fault. 7. Pulley/sprocket slipping on shaft. 8. Motor bearings at fault. 9. Motor at fault. | <ol style="list-style-type: none"> 1. Decrease feed rate. 2. Ensure timber moisture is below 20%. 3. Clear blockages, use smooth wall duct, 4. Clean motor, let cool, and reduce load. 5. Tension/replace belt(s) ensure pulleys are aligned 6. Test/repair/replace. 7. Replace loose pulley/shaft. 8. Test/repair/replace. 9. Test/repair/replace. |
| Excessive step (snipe) (gouge at the end of the workpiece that is uneven with the rest of the cut). | <ol style="list-style-type: none"> 1. One or both of the bed rollers are set too high. 2. Rear table extension slopes down or is not level with the table 3. Chip breaker or pressure bar set too low 4. Workpiece is not fully supported as it leaves the thicknesser. | <ol style="list-style-type: none"> 1. Lower the bed rollers 2. Adjust the rear extension wing set screws to make the extension level with the table 3. Raise the height of the chip breaker or pressure bar 4. Use a roller stands to properly support the workpiece as it leaves the thicknesser. |
| Workpiece stops/slow in the middle of the cut. | <ol style="list-style-type: none"> 1. Depth of cut too deep. 2. Pitch/glue build-up on thicknesser components. 3. One or both of the bed rollers are set too low or too high. 4. Chip breaker or pressure bar set too low 5. Feed rollers set too low or too high. | <ol style="list-style-type: none"> 1. Reduce the depth of cut. 2. Clean planer components with a pitch/resin dissolving solvent. 3. Lower/raise the bed rollers 4. Raise the height of the chip breaker or pressure bar 5. Adjust the feed rollers to the correct height |

OPERATION MANUAL

5.2 Troubleshooting Cont.

| Symptom | Possible Cause | Possible Solution |
|--|--|---|
| Machine has vibration or noisy operation. | <ol style="list-style-type: none"> 1. Belts slapping cover. 2. V-belt(s) worn or loose. 3. Pulley loose. 4. Motor mount loose/broken. 5. Motor fan rubbing on fan cover. 6. Table rollers protruding unevenly. 7. Motor bearings at fault. 8. Cutterhead bearings at fault. 9. Chip deflector hitting cutterhead. | <ol style="list-style-type: none"> 1. Replace/realign belts with a matched set. 2. Inspect/replace belts with a new matched set. 3. Realign/replace shaft, pulley, setscrew, & key. 4. Tighten/replace. 5. Fix/replace fan cover; replace damaged fan. 6. Adjust table rollers. 7. Test by rotating shaft; & replace worn bearings 8. Replace bearing(s)/realign cutterhead. 9. Check/replace chip deflector and realign |
| Consistent chipping pattern. | <ol style="list-style-type: none"> 1. Knots or conflicting grain direction in workpiece. 2. Nicked or chipped cutter or insert. 3. Feed rate too fast. 4. Depth of cut too deep. 5. Bed rollers set too high or low; not even with each other. 6. Misaligned chip breaker. | <ol style="list-style-type: none"> 1. Inspect workpiece for knots and grain direction; use only clean stock. 2. Rotate/replace cutters or insert . 3. Reduce feed rate. 4. Reduce the depth of cut. 5. Properly adjust the bed roller height. 6. Adjust sides of chip breaker until correct |
| Furry grain. | <ol style="list-style-type: none"> 1. Workpiece has high moisture content or surface wetness. 2. Dull cutter blades or inserts | <ol style="list-style-type: none"> 1. Allow workpiece to dry if moisture content is over 20% or has surface wetness. 2. Rotate/replace cutter blades or inserts |
| Lines or ridges running the length of the workpiece | <ol style="list-style-type: none"> 1. Nicked blades or chipped inserts. | <ol style="list-style-type: none"> 1. Rotate or replace the inserts or replace the damaged blades. |
| Uneven cutting marks, wavy surface, or chatter marks on the workpiece. | <ol style="list-style-type: none"> 1. Feed rate too fast. 2. Chip breaker or pressure bar set unevenly. 3. Bed rollers not set correctly. 4. Insert(s) or blades not properly installed. 5. Worn cutterhead bearings. | <ol style="list-style-type: none"> 1. Reduce feed rate. 2. Adjust the height of the chip breaker or pressure bar 3. Properly adjust the bed roller height 4. Remove insert(s) or blades, then properly clean and install 5. Replace cutterhead bearings |
| Glassy surface | <ol style="list-style-type: none"> 1. Inserts are dull. 2. Feed rate too slow. 3. Depth of cut too shallow | <ol style="list-style-type: none"> 1. Rotate/replace inserts or replace blades 2. Increase feed rate 3. Increase depth of cut |
| Inconsistent chip marks. | <ol style="list-style-type: none"> 1. Chips are not being removed from around the cutterhead | <ol style="list-style-type: none"> 1. Use an adequate dust collection system; adjust the chip deflector in or out. |

6. ADJUSTMENTS

6.1 Replacing Cutter Blades

The height of the knives that have been correctly set is crucial to the thicknesser optimum performance. It is very important to keep the knives sharp and with the height of each blade the same. If one blade protrudes higher than the others, it will take most of the load and will dull much faster, and the result will be a poor finish.

As part of the accessories the knife-setting jig is included

To adjust height of blades or replace them:

1. DISCONNECT THE MACHINE FROM POWER!
2. Remove headstock cover to expose the cutter head. Remove the six screws (A), and remove the upper cover (B) as shown in Fig. 6.1.
3. The blades are very sharp so use heavy leather gloves when handling the blades..
4. Remove the upper belt cover, then rotate the cutterhead pulley to provide access to one of the blades.
5. Loosen the cutterhead gib bolts until the blade is completely loose. If the blades are to be replaced, remove the old blade and install the new one, making sure the beveled edge of the new knife is facing the correct direction. (Fig.6.2)
6. Position the blade setting jig over the blade so that blade edge is directly under center pad, as shown in Fig. 6.3
7. Insert a hex wrench into jack screws through access holes in cutterhead. Rotate the jack screws to raise or lower the blade until it barely touches center pad of knife-setting jig with all legs of jig still firmly on cutterhead, then tighten the gib bolts enough to firmly hold the blade in place without fully tightening gib bolts.
8. Incrementally tighten the gib bolts in an even manner, starting at middle and working your way to the ends by alternating left and right.
9. Repeat Step 8, tightening the gib bolts a little more.
10. Repeat Step 8, this time fully tightening all the gib bolts.
11. Repeat Steps 4–8 for remaining knives.




Fig. 6.1




Fig. 6.2




Fig. 6.3

6.2 Replacing Insert Type Cutters

Some models are supplied with a spiral cutterhead equipped with indexable carbide inserts. As they wear they can be rotated to one of their four cutting edges. If one edge of the insert becomes dull or damaged, simply rotate it 90° to reveal a fresh cutting edge. (Fig. 6.4)

The models fitted with the spiral carbide insert cutters are listed below, however the cutters can be purchased as an optional replacement.

T-380S

T-20S

To change or rotate a spiral cutterhead inserts:

1. DISCONNECT THICKNESSER FROM THE POWER!
2. Remove the dust hood, belt cover, and the top cover.
3. Leather heavy gloves should be worn to protect your hands and fingers..
4. Remove any sawdust or debris from around the insert, Torx screw, and the surrounding area.
5. Remove the Torx screw and the insert, then clean both parts and the pocket where the insert sits.

Note: Ensure the insert, Torx, screw, and the cutter head pocket have been thoroughly cleaned. This is critical to achieving a smooth and precision finish. If dirt or dust is trapped between the insert and cutterhead it will slightly raise the insert, and make noticeable marks.

6. Replace the insert so that a fresh cutting edge faces outward. If all four insert cutting edges have been used, replace the insert with a new one. Always position the reference mark (Fig.6.5) on the insert in the same position when installing a new insert to aid in the rotational sequencing.
7. Lubricate the Torx screw threads with a very small amount of light machine oil, wipe the excess off, and tighten the screws making sure not to over tighten them.

Note: Do Not use too much oil. The excess may squeeze out of the threaded hole as you install the insert and force the insert to raise slightly, forcing the insert out of alignment.




Fig. 6.4




Fig. 6.5




Fig. 6.6

6.2 Tensioning and Replacing Drive Belts

Three V-belts transfer power from the motor to the cutterhead, and then through the gearbox and drive chains to the infeed and outfeed rollers. To ensure efficient transfer of power to these systems, make sure the V-belts are always properly tensioned and in good condition. If a V-belt is worn, cracked, or damaged, then replace all three V-belts at the same time with matched V-belts to ensure belt tension is even among the belts.

To Tension Or Replace The V-Belts:

1. DISCONNECT THICKNESSER FROM POWER!
2. Remove the V-belt cover from the left side of the machine to expose the belts.
3. Remove the front cabinet panel to access the motor.
4. If the V-belts need to be replaced, raise the motor to release the belt tension, roll them off the pulleys, then replace them as a matched set of three.
5. To adjust the V-belt tension, loosen the top motor mount hex nuts (Fig. 6.7), then adjust the bottom hex nuts to raise or lower the motor.

Note: The V-belts are correctly tensioned when there is approximately 20mm deflection when moderate pressure is applied to them midway between the pulleys. (Fig. 6.8)




6. When the V-belts are correctly tensioned, make sure the motor mount hex nuts are tight, then replace the cabinet cover and the belt cover.

Table Height Chain Tension

The table height chain transfers movement from the handwheel to elevate the table. This chain can be adjusted to remove slack if it stretches over time or is loosened during table leveling procedures.

To adjust the table height chain tension:

1. DISCONNECT THICKNESSER FROM POWER!
2. Remove the front and rear cabinet panels to gain access to the table height chain system underneath the table. (Fig 6.9)
3. Loosen the lock bolts shown, and push the idler sprocket against the chain with moderate hand pressure, then while maintaining the pressure, re-tighten both lock bolts.




OPERATION MANUAL

6.3 Adjusting Height Of In-feed Roller, Chipbreaker, Pressure Bar & Out-feed Roller



The machine operates at its optimum when the feed rollers, chip breaker, and pressure bar are set at the correct distance below the cutter head allowing the workpiece to move through the thickener evenly and at the correct distance from the cutter head.

The in-feed roller, chipbreaker, pressure bar and out-feed roller are adjusted at the factory. The in-feed roller and the chipbreaker are set 0.1mm below the culling circle, the pressure bar is set 0.2mm below the cutting circle and the out-feed roller is set 0.5mm below the cutting circle, as shown in Fig. 6.10.

To ensure accurate results and make the adjustment process quicker, we recommend using a dial indicator.



1. DISCONNECT THICKNESSER FROM THE POWER SUPPLY!
2. Lower the table at least 100mm below the head casting, then lock it in place.
3. Remove the dust hood, top cover, and belt cover.
4. Using a dial indicator as shown in Fig. 6.11, find the bottom dead centre of any blade edge by slowly rocking the cutterhead pulley back and forth until the dial indicator finds the lowest point, then set the dial indicator to zero.
5. Move the feed speed knob to the neutral position to allow the in-feed roller to freely rotate.
6. Keeping the dial indicator at zero, position it under the right-hand side of the in-feed roller and find the BDC of a serrated edge by rocking the in-feed roller back and forth.
7. Loosen the lock nut and move the set screw (Fig.6.12) to adjust the height of the in-feed roller bushing block until the dial indicator shows 0.1mm, which is the recommended distance for the in-feed roller below the cutter head.
8. Repeat Steps 6–7 on the opposite side of the in feed roller.
9. Re-check both sides of the in-feed roller and, if necessary, make further adjustments, then re-tighten both lock nuts.
10. Keeping the same zero reference on the dial indicator from Step 5, repeat Steps 7–10 for the out-feed roller, but adjust it until it is 0.5mm below the BDC of the cutter head blade.



11. Use the same zero reference on the dial indicator from Step 5, perform similar steps as described above to adjust the height of the chip breaker to its recommended specification given at the beginning of this subsection.

The adjustment controls are shown in Fig. 6.13

12. Re-install the belt cover, top cover, and the dust hood

6.4 Adjusting Kickback Fingers

An important safety feature of your thicknesser are the anti-kickback fingers. The fingers are suspended from a rod across the head casting and in front of the in-feed roller, (Fig. 6.14). These fingers allow the workpiece to enter the thicknesser but reduces the risk of kickback by digging into the workpiece if it moves backward.



The anti-kickback fingers need to be regularly checked to make sure that they move freely. If they do not move easily then clean them with a solvent, and inspect them for any damage. If any are damaged, they must be replaced before the machine is used again. Oil or other lubricants must not be placed on the antikickback fingers. Lubricants will attract dust and restrict the free movement of the fingers.

6.5 Positioning The Chip Deflector

When properly distanced from the cutterhead, the chip deflector keeps chips from falling onto the out-feed roller and being pressed into the workpiece.

To adjust

1. DISCONNECT THE THICKNESSER FROM POWER!
2. Remove the dust chute, belt cover, and top cover.
3. Rotate the cutterhead pulley until a blade of the cutter head is nearest the chip deflector, then measure that distance between the chip deflector and the blade. (Fig. 6.15).
If the distance measured in Step 3 is not 6mm then loosen the four hex bolts that secure the chip deflector and adjust the gap to 6mm.
4. Repeat Step 3 for the other end of the cutter head.
5. Re-tighten the hex bolts, then replace the belt cover, top cover, and dust hood.



6.6 SETTING DIGITAL READOUT

The machines are fitted with a digital height gauge (Fig.6.16) which needs to be set before the machine is used. Once the digital display is set and switched off the settings will be stored ready for the next time the display is switched on. Re-setting should only be needed if the battery is changed. The display can read in either "mm" or inches. (Battery is LR-44)

To set the display

1. Switch the display "ON."
2. Plane a piece of wood and measure its thickness, do not move the hand wheel after this.
3. Press the "SET" button and hold for approx. 2 seconds until the "+" sign starts flashing on the screen.
3. To change the "+" to a "-" (if required – otherwise go to step 4.), press the "SET" button once.
4. Press the "SET" button and hold for approx. 2 seconds until the 1st digit starts flashing on the screen.
5. To change the 1st digit, press the "SET" button. Every time you press the "SET" button, the 1st digit will increase by 1.
6. To move across to the second digit press and hold the set button for 2 secs. until the second digit flashes. Every time you press the "SET" button, the 2nd digit will increase by 1. Continue to move across the digits by holding the "SET" button for 2 secs. until completed.
7. Press the "SET" button once more to complete.



Fig. 6.16

The DRO should now be set to display the thickness of the wood as planned.

ABS Button

The digital display allows for a switching between "Absolute" and "Incremental" measurement.

How to use the "ABS" button.

Example

If the screen displays 100mm, when the ABS button is pressed the display is changed to "Zero" and "INC" is displayed on the screen. If the table is now lowered 10mm then -10mm is display. When the ABS button is pressed again then the screen will display 90mm (the 100mm less the 10mm)

The incremental setting can be used as many times as is needed without loosing the absolute measurement.



Fig. 6.16

SPARE PARTS SECTION

The following section covers the spare parts diagrams and lists that were current at the time this manual was originally printed. Due to continuous improvements of the machine, changes may be made at any time without notification.

HOW TO ORDER SPARE PARTS

1. Have your machines **model number, serial number & date of manufacture** on hand, these can be found on the specification plate mounted on the machine
2. A scanned copy of your parts list/diagram with required spare part/s identified
3. Go to www.machineryhouse.com.au/contactus and fill out the enquiry form attaching a copy of scanned parts list.

CONTENTS

| | |
|--|----|
| Parts Diagram For W414 & W414S..... | 32 |
| Parts List For W414 & W414S..... | 33 |
| Parts Diagram For W415, W415A & W415S..... | 36 |
| Parts List For W415, W415A & W415S..... | 37 |
| Risk Assesment..... | 41 |

OPERATION MANUAL

PARTS LIST FOR W414 & W414S

| Item | Part Number | Description | Specification | Qty. |
|------|-------------|---------------------------|-------------------------|------|
| 1 | 230118-000 | NUT | | 2 |
| 2 | 170417-000 | BELT HQUSING | | 1 |
| 3 | 014003-000 | BELT | M40 | 3 |
| 4 | 380147-901 | BOLT | | 2 |
| 5 | 000902-202 | HEX SCREW W/ WASHER | M6*1.0P*12 | 26 |
| 6 | 170418-000 | PULLEY COVER | | 1 |
| 7 | 006002-046 | FLAT WASHER | 8.5*16*1.5t | 2 |
| 8 | 009005-200 | HEX NUT | 5/16"-18NC(12.7B*6.75H) | 2 |
| 9 | 000003-204 | HEX SCREW | M8*1.25P*20 | 4 |
| 10 | 006001-043 | FLAT WASHER | 8.2 *30*4.0t | 1 |
| 11 | 200013-615 | PLATE | | 2 |
| 12 | 012003-003 | KEY | 5*5*12 | 1 |
| 13 | 920351-000 | UPER COVER | | 1 |
| 17 | 000103-107 | CAP SCREW | M6*1.0P*20 | 19 |
| 18 | 050288-000 | ROLLER BRACKET | | 3 |
| 19 | 012002-004 | KEY | 4*4*10 | 1 |
| 20 | 240015-000 | HANDWHEEL | | 1 |
| 22 | 006002-067 | FLAT WASHER | 10*20*1.5t | 4 |
| 23 | 008008-200 | HEX NUT | M10*1.25P(17B*8H) | 6 |
| 25 | 250158-617 | CHIP DEFLECTOR | | 1 |
| 26 | 000002-101 | HEX SCREW | M6*1.0P*12 | 4 |
| 27 | 006001-056 | FLAT WASHER | 8.5*23*2.0t | 8 |
| 28 | 270015-901 | SPRING PLATE | | 3 |
| 29 | 380200-901 | SCREW | | 4 |
| 30 | 006001-041 | FLAT WASHER | 8.2*22*3.0t | 3 |
| 31 | 170405-901 | BRACKET | | 1 |
| 32 | 290039-901 | SHAFT | | 1 |
| 33 | 130071-000 | TENSION WHEEL | | 1 |
| 34 | 360349-902 | SHAFT | | 1 |
| 35 | 011004-102 | SPRING PIN | 6*20 | 2 |
| 36 | 050276-000 | COVER | | 1 |
| 37 | 000104-114 | CAP SCREW | M8*1.25P*50 | 4 |
| 38 | 000203-106 | SET SCREW | M6*1.0P*16 | 5 |
| 39 | 280050-000 | SPRING | | 1 |
| 40 | 170406-901 | HANGER | | 1 |
| 41 | 033706-000 | NBALL BEARING | 6205-NKE | 1 |
| 42 | 000103-102 | CAP SCREW | M6*1.0P*10 | 2 |
| 43 | 012204-001 | KEY | 8*8*36 | 1 |
| 44 | 922025-000 | CUTTERHEAD (MODEL T-380S) | SPIRAL | 1 |
| 44 | 922355-000 | CUTTERHEAD (MODEL T-380) | FLAT | 1 |
| 45 | 937737-000 | MAG SWITCH (MODEL T-380S) | 3HP 240V 1PH | 1 |
| 45 | 937002-000 | MAG SWITCH (MODEL T-380) | 2HP 240V 1PH | 1 |
| 46 | 000205-101 | SET SCREW | M10*1.5P*12 | 15 |
| 47 | 000204-103 | SET SCREW | M8*1.25P*12 | 1 |
| 48 | 280051-000 | SPRING | | 4 |
| 49 | 130039-000 | BUSHING | | 4 |
| 50 | 170408-902 | PLATE | | 4 |

OPERATION MANUAL

PARTS LIST FOR W414 & W414S

| Item | Part Number | Description | Specification | Qty. |
|------|-------------|----------------------|--------------------|------|
| 51 | 008005-200 | HEX NUT | | 6 |
| 52 | 050282-000 | HEAD CASTING | | 1 |
| 53 | 360383-000 | OUTFEED ROLLER | | 1 |
| 54 | 170409-901 | DEPTH LIMITER | | 1 |
| 55 | 000402-202 | FLAT HD SCREW | M5*0.8P*8 | 2 |
| 56 | 012202-001 | KEY | 5*5*22 | 2 |
| 57 | 070012-000 | SPROCKET | | 1 |
| 58 | 006001-020 | FLAT WASHER | 6.2*20*3.0t | 1 |
| 59 | 000002-203 | HEX SCREW | M6*1.0P*16 | 3 |
| 60 | 016306-000 | CHAIN | #06B*63P | 1 |
| 61 | 920488-000 | MOTOR PULLEY | | 1 |
| 63 | 010003-000 | S-CLIP | STW-12 | 1 |
| 64 | 360351-000 | ADJUST ROD | | 1 |
| 65 | 360366-902 | LOCKING ROD | | 1 |
| 66 | 008009-200 | HEX NUT | M12*1.75P(19B*10H) | 1 |
| 67 | 010209-000 | E-CLIP | ETW-15 | 2 |
| 68 | 250160-615 | COLLAR | | 40 |
| 69 | 172281-905 | ANTI-KICKBACK FINGER | | 39 |
| 70 | 360352-000 | SHAFT | | 1 |
| 71 | 360353-000 | INFEED ROLLER | | 1 |
| 72 | 070013-000 | SPROCKET | | 1 |
| 73 | 000103-103 | CAP SCREW | M6*1.0P*12 | 1 |
| 74 | 030109-000 | BALL BEARING | 6204-ZZ | 1 |
| 75 | 320196-000 | GEAR | | 1 |
| 76 | 000103-108 | CAP SCREW | M6*1.0P*25 | 6 |
| 77 | 030701-000 | BALL BEARING | 6201 | 2 |
| 78 | 320197-000 | GEAR | | 1 |
| 79 | 320160-000 | GEAR AND SHAFT | | 1 |
| 80 | 012003-002 | KEY | 5*5*10 | 1 |
| 81 | 050280-000 | GEAR CASE | | 1 |
| 82 | 360355-901 | PIN | | 2 |
| 83 | 030304-000 | BALL BEARING | 6201Z(A) | 3 |
| 84 | 320205-000 | SHAFT | | 1 |
| 85 | 012004-003 | KEY | 6*6*40 | 1 |
| 86 | 320198-000 | GEAR | | 1 |
| 87 | 250372-615 | KNOB | | 1 |
| 88 | 016303-000 | CHAIN | #06B*47P | 1 |
| 89 | 150008-000 | SPROCKET | | 1 |
| 90 | 043401-000 | OIL PLUG | PT1/4"-19 | 2 |
| 91 | 043608-000 | OIL SEAL | TC28*40*8 | 1 |
| 92 | 050281-000 | GEAR BOX | | 1 |
| 93 | 340012-615 | GASKET | | 1 |
| 94 | 922351-000 | DOUBLE GEAR | | 1 |
| 95 | 360375-902 | ROLLER | | 2 |
| 96 | 360357-901 | SHAFT | | 1 |
| 97 | 280052-000 | SPRING | | 1 |
| 98 | 017002-000 | BALL | 6 | 1 |
| 99 | 043505-000 | OIL SEAL | SC25*47*6 | 1 |
| 100 | 030306-000 | BALL BEARING | 6204Z(A) | 1 |

OPERATION MANUAL


PARTS LIST FOR W414 & W414S

| Item | Part Number | Description | Specification | Qty. |
|------|-------------|-----------------|---------------|------|
| 102 | 070014-000 | SHIFTER | | 1 |
| 103 | 360358-901 | SHIFTING SHAFT | | 1 |
| 104 | 043303-000 | O-RING | P12 | 1 |
| 105 | 922365-000 | ROLLER ASSEMBLY | | 2 |
| | 170422-008 | BRACKET | | 1 |
| | 190044-906 | ROLLER | | 1 |
| | 360370-901 | SHAFT | | 1 |
| | 250251-615 | BUSHING | | 2 |
| | 000002-201 | HEX SCREW | M6*1.0P*12 | 2 |
| | 006002-034 | FLAT WASHER | 6.7*16*2.0t | 2 |
| | 520001-237 | BOX | 410*285*55 | 1 |
| 106 | 041503-017 | PLASTIC PLATE | 570*440*0.05t | 1 |
| 107 | 360360-902 | SHAFT | | 4 |
| 109 | 921209-000 | ROLLER | | 2 |
| 110 | 230115-000 | NUT | | 2 |
| 111 | 130037-000 | GIB BOLT | | 2 |
| 112 | 360350-902 | LEAD SCREW | | 2 |
| 113 | 050283-000 | MIDDLE TABLE | | 1 |
| 114 | 000203-104 | SET SCREW | M6*1.0P*12 | 11 |
| 115 | 130038-000 | GIB BOLT | | 2 |
| 116 | 002301-201 | RIVET | 2*5 | 2 |
| 117 | 130043-000 | NUT | | 4 |
| 118 | 360359-000 | SHORT LEADSCREW | | 3 |
| 119 | 050284-000 | COLUMN | | 3 |
| 120 | 016220-000 | CHAIN | #410*134P | 1 |
| 121 | 010006-000 | S-CLIP | STW-15 | 1 |
| 122 | 150009-000 | SPROCKET | | 1 |
| 123 | 360362-902 | SHAFT | | 1 |
| 124 | 170413-901 | BRACKET | | 1 |
| 125 | 050285-000 | BASE | | 1 |
| 126 | 000003-205 | HEX SCREW | M8*1.25P*25 | 2 |
| 127 | 030305-000 | BALL BEARING | 6202Z(A) | 4 |
| 128 | 010103-000 | R-CLIP | RTW-35 | 4 |
| 129 | 150010-000 | SPROCKET | | 4 |
| 130 | 050286-000 | COLUMN | | 1 |
| 131 | 570889-000 | SCALE | | 1 |
| 132 | 000301-201 | SCREW | M3*0.5P*6 | 2 |
| 133 | 010208-000 | E-CLIP | ETW-12 | 4 |
| 134 | 360367-902 | LIFT SHAFT | | 4 |
| 135 | 010001-000 | S-CLIP | STW-10 | 1 |
| 136 | 320201-000 | GEAR | | 1 |
| 137 | 010104-000 | R-CLIP | RTW-38 | 1 |
| 138 | 130041-000 | BUSHING | | 1 |
| 139 | 360372-000 | LONG LEADSCREW | | 1 |
| 141 | 170420-000 | STAND | | 1 |
| 142 | 170421-000 | PANEL | | 1 |
| 143 | 000403-204 | SCREW | M6*1.0P*20 | 8 |
| 144 | 000003-109 | HEX SCREW | M8*1.25P*45 | 4 |
| 146 | 050287-008 | MOTOR MOUNT | | 1 |



OPERATION MANUAL

PARTS FOR W415, W415A & W415S



OPERATION MANUAL

PARTS LIST FOR W415, W415A & W415S

| Item | Part Number | Description | Specification | Qty. |
|------|-------------|---------------------------|-------------------------|------|
| 1 | 230118-000 | NUT | | 2 |
| 2 | 170431-000 | PULLEY COVER | | 1 |
| 3 | 014010-000 | BELT | M59 | 3 |
| 4 | 380147-901 | BOLT | | 2 |
| 5 | 000003-204 | HEX SCREW | M8*1.25P*20 | 6 |
| 6 | 006001-043 | FLAT WASHER | 8.2(+0.2/-0)*30*4.0t | 2 |
| 7 | 000902-202 | HEX SCREW WITH WASHER | M6*1.0P*12 | 15 |
| 8 | 170432-000 | PULLEY GUARD | | 1 |
| 9 | 009005-200 | HEX NUT | 5/16"-18NC(12.7B*6.75H) | 2 |
| 10 | 050273-901 | CUTTERHEAD PULLEY | | 1 |
| 12 | 920265-000 | COLLECTOR TUBE | | 1 |
| 13 | 000002-201 | HEX SCREW | M6*1.0P*12 | 4 |
| 14 | 006002-032 | FLAT WASHER | 6.6*13*1.0t | 7 |
| 15 | 000103-103 | CAP SCREW | M6*1.0P*12 | 9 |
| 16 | 170494-000 | UPPER COVER | | 1 |
| 17 | 006001-056 | FLAT WASHER | 8.5*23*2.0t | 10 |
| 18 | 000103-106 | CAP SCREW | M6*1.0P*16 | 9 |
| 19 | 920263-000 | HANDWHEEL | | 1 |
| 21 | 200021-000 | SPONGE | | 1 |
| 22 | 250172-617 | CHIP DEFLECTOR | | 1 |
| 23 | 270015-901 | PLATE SPRING | | 3 |
| 24 | 000203-106 | SET SCREW | M6*1.0P*16 | 9 |
| 25 | 270017-901 | PLATE SPRING | | 1 |
| 26 | 380200-901 | SCREW | | 4 |
| 27 | 006001-041 | FLAT WASHER | 8.2*22*3.0t | 3 |
| 28 | 170405-901 | BRACKET | | 1 |
| 29 | 290039-901 | SHAFT | | 1 |
| 30 | 130071-000 | IDLE PULLEY | | 1 |
| 31 | 360349-902 | SHAFT | | 1 |
| 32 | 170473-904 | SAFETY HATCH | | 1 |
| 33 | 011004-102 | SPRING PIN | 6*20 | 2 |
| 34 | 050292-000 | COVER | | 1 |
| 35 | 000104-112 | CAP SCREW | M8*1.25P*40 | 1 |
| 36 | 280050-000 | SPRING | | 1 |
| 37 | 170406-901 | HANGER | | 1 |
| 38 | 921246-000 | DIGITAL READOUT | | 1 |
| 39 | 006002-046 | FLAT WASHER | 8.5*16*1.5t | 2 |
| 41 | 170475-904 | SAFETY | | 1 |
| 42 | 937009-000 | MAG SWITCH (MODEL T-20) | 3HP*240V*50HZ*1PH | 1 |
| 42 | 937461-000 | MAG SWITCH (MODEL T-20) | 5HP*415V*50HZ*3PH | 1 |
| 42 | 937738-000 | MAG SWITCH (MODEL T-20S) | 5HP*415V*50HZ*3PH | 1 |
| 43 | 000205-101 | SET SCREW | M10*1.5P*12 | 15 |
| 44 | 000204-103 | SET SCREW | M8*1.25P*12 | 6 |
| 45 | 050293-000 | CASTING HEAD | | 1 |
| 46 | 360385-901 | SHAFT | | 2 |
| 47 | 002301-201 | RIVET | 2*5 | 4 |
| 48 | 008005-200 | HEX NUT | M6*1.0P(10B*5H) | 6 |
| 49 | 000203-107 | SET SCREW | M6*1.0P*20 | 2 |
| 50 | 000402-202 | FLAT HEAD MACHINE SCREW | M5*0.8P*8 | 2 |

OPERATION MANUAL

PARTS LIST FOR W415, W415A & W415S

| Item | Part Number | Description | Specification | Qty. |
|------|-------------|--------------------------|--------------------|------|
| 51 | 170409-901 | CUT LIMITER PLATE | | 1 |
| 54 | 033705-000 | BALL BEARING | 6206-2NKE | 1 |
| 55 | 012204-001 | KEY | 8*8*36 | 1 |
| 56 | 920734-000 | CUTTERHEAD (MODEL T-20) | FLAT | 1 |
| 56 | 922045-000 | CUTTERHEAD (MODEL T-20S) | SPIRAL | 1 |
| 58 | 280051-000 | SPRING | | 4 |
| 59 | 130039-000 | BUSHING | | 4 |
| 60 | 170408-902 | PLATE | | 4 |
| 61 | 006305-100 | LOCK WASHER | 8.2*15.4 | 3 |
| 62 | 170477-019 | PRESSURE PLATE | | 1 |
| 63 | 360405-000 | OUTFEED ROLLER | | 1 |
| 64 | 012003-008 | KEY | 5*5*22 | 2 |
| 65 | 070012-000 | SPROCKET | | 1 |
| 66 | 006001-020 | FLAT WASHER | 6.2*20*3.0t | 4 |
| 67 | 000002-203 | HEX SCREW | M6*1.0P*16 | 3 |
| 68 | 070016-025 | BRACKET | | 2 |
| 69 | 360386-000 | SHAFT | | 1 |
| 70 | 170478-000 | CHIP BREAKER | | 1 |
| 71 | 070013-000 | SPROCKET | | 1 |
| 72 | 010003-000 | RETAINING RING | STW-12 | 2 |
| 73 | 010209-000 | RETAINING RING | ETW-15 | 2 |
| 74 | 250160-615 | COLLAR | | 56 |
| 75 | 172281-905 | ANTI-KICKBACK FINGER | | 55 |
| 76 | 360387-000 | LOCKING BOLT | | 1 |
| 77 | 360388-000 | SHAFT | | 1 |
| 78 | 008009-200 | HEX NUT | M12*1.75P(19B*10H) | 2 |
| 79 | 360389-000 | INFEED ROLLER | | 1 |
| 80 | 016308-002 | CHAIN | #06B*67P | 1 |
| 81 | 000104-114 | CAP SCREW | M8*1.25P*50 | 4 |
| 82 | 030109-000 | BALL BEARING | 6204-ZZ | 1 |
| 83 | 320196-000 | GEAR | | 1 |
| 84 | 000103-108 | CAP SCREW | M6*1.0P*25 | 5 |
| 85 | 030701-000 | BALL BEARING | #6201 | 2 |
| 86 | 320197-000 | GEAR | | 1 |
| 87 | 320160-000 | SHAFT | | 1 |
| 88 | 012003-003 | KEY | 5*5*12 | 1 |
| 89 | 050280-000 | COVER | | 1 |
| 90 | 360355-901 | PIN | | 2 |
| 92 | 320205-000 | SHAFT | | 1 |
| 93 | 012004-003 | KEY | 6*6*40 | 1 |
| 94 | 012003-002 | KEY | 5*5*10 | 1 |
| 95 | 320198-000 | GEAR | | 1 |
| 96 | 250372-615 | HANDLE | | 1 |
| 97 | 920744-000 | SPROCKET & CHAIN ASSY | 16/20FPM | 1 |
| 99 | 043401-000 | OIL PLUG | PT1/4"-19 | 2 |
| 100 | 043608-000 | OIL SEAL | TC28*40*8 | 1 |
| 101 | 050281-000 | WORM GEAR BOX | | 1 |
| 102 | 340012-615 | GASKET | | 1 |
| 103 | 922351-000 | GEAR | | 1 |

OPERATION MANUAL

PARTS LIST FOR W415, W415A & W415S

| Item | Part Number | Description | Specification | Qty. |
|------|-------------|--------------------------|-------------------------|------|
| 104 | 000902-203 | HEX SCREW WITH WASHER | M6*1.0P*16 | 5 |
| 105 | 360357-901 | SHAFT | | 1 |
| 106 | 280052-000 | SPRING | | 1 |
| 107 | 017002-000 | BALL | 6mm | 1 |
| 108 | 043505-000 | OIL SEAL | SC25*47*6 | 1 |
| 109 | 030306-000 | BALL BEARING | 6204Z(A) | 1 |
| 111 | 070014-000 | CLUTCH | | 1 |
| 112 | 360358-901 | SHAFT | | 1 |
| 113 | 043303-000 | OIL RING | P12 | 1 |
| 114 | 041503-018 | PLASTIC PLATE | 720*570*0.05t | 1 |
| 118 | 130038-000 | LOCKING BAR | | 2 |
| 119 | 360390-000 | LOCKING BOLT | | 2 |
| 120 | 000104-104 | CAP SCREW | M8*1.25P*16 | 7 |
| 121 | 360391-000 | ECCENTRIC SHAFT | | 4 |
| 122 | 922032-000 | EXTENSION ROLLER ASSY. | | 1 |
| 1.1 | 050294-000 | MIDDLE TABLE | | 1 |
| 1.2 | 920746-000 | ROLLER ASSY | | 2 |
| 1.3 | 850399-000 | EXTENSION HARDWARE | | 1 |
| 116 | 000004-202 | HEX SCREW | M10*1.5P*25 | 8 |
| 117 | 006001-095 | FLAT WASHER | 13.5*32*2.3t | 8 |
| 183 | 041103-001 | PLASTIC BAG | 120*100*0.1t | 1 |
| 123 | 130037-000 | LOCKING BAR | | 2 |
| 124 | 230115-000 | KNOB | | 2 |
| 125 | 000203-104 | SET SCREW | M6*1.0P*12 | 4 |
| 126 | 030304-000 | BALL BEARING | 6201Z(A) | 4 |
| 127 | 921208-000 | ROLLER | | 2 |
| 128 | 000403-204 | SCREW | M6*1.0P*20 | 8 |
| 129 | 170479-000 | COVER | | 2 |
| 130 | 170480-000 | MOTOR MOUNT | | 1 |
| 131 | 006002-091 | FLAT WASHER | 13*28*3.0t | 13 |
| 132 | 000005-202 | HEX SCREW | M12*1.75P*50 | 4 |
| 134 | 190074-901 | COLLAR | | 1 |
| 137 | 900025-000 | MOTOR ASSY (MODEL T-20) | 3HP*240V*50HZ*1PH | 1 |
| 137 | 900018-000 | MOTOR ASSY (MODEL T-20) | 5HP*415V*50HZ*3PH (160) | 1 |
| 137 | 901135-000 | MOTOR ASSY (MODEL T-20S) | 5HP*415V*50HZ*3PH (190) | 1 |
| 138 | 008009-100 | HEX NUT | M12*1.75P(19B*10H) | 8 |
| 139 | 000003-208 | HEX SCREW | M8*1.25P*40 | 4 |
| 141 | 000003-106 | HEX SCREW | M8*1.25P*30 | 2 |
| 142 | 006001-046 | FLAT WASHER | 8.5*16*1.5t | 6 |
| 143 | 360394-000 | SUPPORT SHAFT | | 2 |
| 144 | 380249-901 | ADJUSTING BOLT | | 2 |
| 145 | 008006-200 | HEX NUT | M8*1.25P(13B*6.5H) | 4 |
| 146 | 130045-000 | NUT | | 4 |
| 147 | 360395-000 | LEAD SCREW (SHORT) | | 3 |
| 148 | 050296-000 | COLUMN | | 3 |
| 149 | 050297-000 | BASE | | 1 |
| 150 | 016004-000 | CHAIN | #40*166P | 1 |
| 151 | 170413-901 | BRACKET | | 1 |
| 152 | 360362-902 | SHAFT | | 1 |

OPERATION MANUAL

PARTS LIST FOR W415, W415A & W415S

| Item | Part Number | Description | Specification | Qty. |
|------|-------------|------------------------|-----------------------|------|
| 153 | 150011-000 | SPROCKET | | 1 |
| 154 | 010006-000 | RETAINING RING | STW-15 | 1 |
| 155 | 000003-205 | HEX SCREW | M8*1.25P*25 | 1 |
| 156 | 030305-000 | BALL BEARING | 6202Z(A) | 4 |
| 157 | 010103-000 | RETAINING RING | RTW-35 | 4 |
| 158 | 150012-000 | SPROCKET | | 4 |
| 159 | 006001-078 | FLAT WASHER | 10.5*19*1.5t | 4 |
| 160 | 008008-100 | HEX NUT | M10*1.25P(17B*8H) | 4 |
| 161 | 250173-615 | EXPANSION BEND | | 8 |
| 162 | 001104-502 | SCREW | M5*2.12P*10 | 30 |
| 163 | 170481-901 | RING | | 16 |
| 164 | 050298-000 | COLUMN | | 1 |
| 165 | 010202-000 | RETAINING RING | ETW-17 | 4 |
| 166 | 360396-902 | LIFT SHAFT | | 4 |
| 167 | 320203-000 | GEAR | | 1 |
| 168 | 010104-000 | RETAINING RING | RTW-38 | 1 |
| 169 | 130046-000 | BUSHING | | 1 |
| 170 | 012002-004 | KEY | 4*4*10 | 2 |
| 171 | 360397-000 | LEAD SCREW (LONG) | | 1 |
| 172 | 021306-000 | STRAING LELIEF | PGA16-14B | 1 |
| 190 | 050299-000 | ROLLER STAND | | 3 |
| 191 | 360398-902 | ROLLER | | 2 |
| 192 | 050300-000 | WORM GEAR | | 1 |
| 193 | 000103-113 | CAP SCREW | M6*1.0P*50 | 3 |
| 194 | 320204-000 | SHAFT | | 1 |
| 196 | 010102-000 | RETAINING RING | RTW-32 | 1 |
| 197 | 190008-901 | COLLAR | | 1 |
| 198 | 940119-000 | MANUAL | | 1 |
| 199 | 945608-000 | LABELS | MODEL T-20 (1PH 240V) | 1 |
| 199 | 944867-000 | LABELS | MODEL T-20 (3PH 415V) | 1 |
| 199 | 945567-000 | LABELS | MODEL T-20S | 1 |
| 200 | 000103-102 | CAP SCREW | M6*1.0P*10 | 2 |
| 205 | 048201-204 | HEX LOCKING SCREW | M8*1.25P*30 | 1 |
| 208 | 021336-000 | STRAING LELIEF | MG25A-16B | 1 |
| 210 | 008304-200 | LOCKUNG NUT | M6*1.0P(10B*7H) | 2 |
| 211 | 000303-105 | SCREW | M5*0.8P*15 | 2 |
| | 850220-000 | HARDWARE BAG | | 1 |
| 20 | 230114-906 | HANDLE | | 1 |
| 176 | 040003-000 | HEX SCREW | 3mm | 1 |
| 177 | 040004-000 | HEX SCREW | 4mm | 1 |
| 178 | 040005-000 | HEX SCREW | 5mm | 1 |
| 179 | 040006-000 | HEX SCREW | 6mm | 1 |
| 180 | 040201-000 | OPEN WRENCH | 8*10 | 1 |
| 181 | 040204-000 | OPEN WRENCH | 12*14 | 1 |
| 182 | 040206-000 | OPEN WRENCH | 17*19 | 1 |
| 184 | 041203-006 | PLASTIC BAG | 610*110*0.15t | 1 |
| | 850114-000 | DUST HOOD HARDWARE BAG | | 1 |
| 13 | 000002-201 | HEX SCREW | M6*1.0P*12 | 6 |
| 14 | 006002-032 | FLAT WASHER | 6.6*13*1.0t | 6 |
| 183 | 041103-001 | PLASTIC BAG | 120*100*0.1t | 1 |



General Machinery Safety Instructions

Machinery House
requires you to read this entire Manual before using this machine.

- 1. Read the entire Manual before starting machinery.** Machinery may cause serious injury if not correctly used.
- 2. Always use correct hearing protection when operating machinery.** Machinery noise may cause permanent hearing damage.
- 3. Machinery must never be used when tired, or under the influence of drugs or alcohol.** When running machinery you must be alert at all times.
- 4. Wear correct Clothing.** At all times remove all loose clothing, necklaces, rings, jewelry, etc. Long hair must be contained in a hair net. Non-slip protective footwear must be worn.
- 5. Always wear correct respirators around fumes or dust when operating machinery.** Machinery fumes & dust can cause serious respiratory illness. Dust extractors must be used where applicable.
- 6. Always wear correct safety glasses.** When machining you must use the correct eye protection to prevent injuring your eyes.
- 7. Keep work clean and make sure you have good lighting.** Cluttered and dark shadows may cause accidents.
- 8. Personnel must be properly trained or well supervised when operating machinery.** Make sure you have clear and safe understanding of the machine you are operating.
- 9. Keep children and visitors away.** Make sure children and visitors are at a safe distance for you work area.
- 10. Keep your workshop childproof.** Use padlocks, Turn off master power switches and remove start switch keys.
- 11. Never leave machine unattended.** Turn power off and wait till machine has come to a complete stop before leaving the machine unattended.
- 12. Make a safe working environment.** Do not use machine in a damp, wet area, or where flammable or noxious fumes may exist.
- 13. Disconnect main power before service machine.** Make sure power switch is in the off position before re-connecting.
- 14. Use correct amperage extension cords.** Undersized extension cords overheat and lose power. Replace extension cords if they become damaged.
- 15. Keep machine well maintained.** Keep blades sharp and clean for best and safest performance. Follow instructions when lubricating and changing accessories.
- 16. Keep machine well guarded.** Make sure guards on machine are in place and are all working correctly.
- 17. Do not overreach.** Keep proper footing and balance at all times.
- 18. Secure workpiece.** Use clamps or a vice to hold the workpiece where practical. Keeping the workpiece secure will free up your hand to operate the machine and will protect hand from injury.
- 19. Check machine over before operating.** Check machine for damaged parts, loose bolts, Keys and wrenches left on machine and any other conditions that may effect the machines operation. Repair and replace damaged parts.
- 20. Use recommended accessories.** Refer to instruction manual or ask correct service officer when using accessories. The use of improper accessories may cause the risk of injury.
- 21. Do not force machinery.** Work at the speed and capacity at which the machine or accessory was designed.
- 22. Use correct lifting practice.** Always use the correct lifting methods when using machinery. Incorrect lifting methods can cause serious injury.
- 23. Lock mobile bases.** Make sure any mobile bases are locked before using machine.
- 24. Allergic reactions.** Certain metal shavings and cutting fluids may cause an allergic reaction in people and animals, especially when cutting as the fumes can be inhaled. Make sure you know what type of metal and cutting fluid you will be exposed to and how to avoid contamination.
- 25. Call for help.** If at any time you experience difficulties, stop the machine and call you nearest branch service department for help.



Planer Thicknesser Safety Instructions

Machinery House

requires you to read this entire Manual before using this machine.

- 1. Maintenance.** Make sure the Planer Thicknesser is turned off and disconnect from the main power supply and make sure all moving parts have come to a complete stop before any inspection, adjustment or maintenance is carried out.
- 2. Planer Thicknesser Condition.** Planer Thicknesser must be maintained for a proper working condition. Never operate a Planer Thicknesser that has damaged or worn parts. Scheduled routine maintenance should be performed on a scheduled basis.
- 3. Blade/Cutter Condition.** Never operate a Planer Thicknesser with dropped, cracked or badly worn blades or cutters. Before using a Planer Thicknesser inspect all blades and cutters. A damaged blade or cutter can cause serious injury.
- 4. Hand Hazard.** Keep hands and fingers clear from the cutter-head, infeed & outfeed table supports. Serious injury can occur.
- 5. Leaving a Planer Thicknesser Unattended.** Always turn the Planer Thicknesser off and make sure all moving parts have come to a complete stop before leaving the Planer Thicknesser. Do not leave Planer Thicknesser running unattended for any reason.
- 6. Avoiding Entanglement.** Blade guard must be used at all times. Remove loose clothing, belts, or jewelry items. Never wear gloves while machine is in operation. Tie up long hair and use the correct hair nets to avoid any entanglement with the Planer Thicknesser moving parts.
- 7. Understand the machines controls.** Make sure you understand the use and operation of all controls.
- 8. Power outage.** In the event of a power failure during use of the Planer Thicknesser, turn off all switches to avoid possible sudden start up once power is restored.
- 9. Work area hazards.** Keep the area around the Planer Thicknesser clean from oil, tools, chips. Pay attention to other persons in the area and know what is going on around the area to ensure unintended accidents.
- 10. Workpiece Handling.** Supporting the work-piece adequately with additional supports at all times while cutting. This is crucial for making safe cuts and avoiding injury. Never attempt to make a cut with an unstable work-piece. Ensure work piece has stopped feeding before handling.
- 11. Hearing protection and hazards.** Always wear hearing protection as noise generated from cutter-head and work-piece vibration can cause permanent hearing loss over time.
- 12. Thicknesser Infeed clearance safety.** The infeed roller is designed to pull the work-piece into the cutter-head. Always keep hands, clothing, hair away from the infeed roller during operation to prevent serious injury.
- 13. Never look inside thicknesser.** Wood chips fly around inside the thicknesser at a high rate of speed. Do not look inside the thicknesser remove guards or covers during operation.
- 14. Operating position.** The work-piece may kick out during operation. To avoid getting hit, stand to the side of the machine during the entire operation.
- 15. Use correct material.** Only use natural timber. Do not use MDF, plywood, laminates, or other synthetic or man-made products. Thicknessing material not designed for this machine may cause serious injury.
- 16. Planer Cutter-head Alignment.** The top edge of the out-feed table should be aligned with the edge of the knife at top dead centre to avoid kickback. An unaligned table can cause serious injury.
- 17. Joining with the grain.** Jointing against the grain or jointing end grain is dangerous and could produce chatter or excessive chip out. Always joint with the grain.
- 18. Thicknessing Grain direction.** Thicknessing across the grain may cause the work-piece to kick out. Always thickness with the wood grain or at a small angle.
- 19. Use a Push Stick.** Always use a push stick when whenever surface planing. Never pass your hands directly over the cutter-head without a push stick.
- 20. Blade guards.** Always use blade guards except when rebating. Make sure you replace the guard after rebating.
- 21. Planer Cutting operation.** Always keep the work-piece moving toward the outfeed table until the work-piece has passed completely over the cutter-head. Never feed the work-piece toward the infeed table.
- 22. Stalled blade.** In the case that the cutter-head stalls while in operation, turn the Planer Thicknesser off before freeing the stalled cutter-head.
- 23. Changing between Planer / Thicknesser mode.** Once changed to the required mode either Planer or Thicknesser, always ensure all safety guards and dust chutes are re-fitted before starting machine.
- 24. Work-piece safety.** Inspect your work-piece carefully before feeding it over the cutter-head. Never thickness material that has knots, nails, or staples.
- 25. Dust hazards.** Always use a dust collector when using machine.
- 26. Kickback.** Kickback is defined as high speed expulsion of work-piece from the Planer Thicknesser table cutter-head. Never stand in the kickback zone.
- 27. Call for help.** If at any time you experience difficulties, stop the machine and call your nearest branch service department for help.

PLANT SAFETY PROGRAM

NEW MACHINERY HAZARD IDENTIFICATION, ASSESSMENT & CONTROL

Planer Thicknesser

Developed in Co-operation Between A.W.I.S.A and Australia Chamber of Manufactures
This program is based upon the Safe Work Australia, Code of Practice - Managing Risks of Plant in the Workplace (WHSA 2011 No10)

| Item No. | Hazard Identification | Hazard Assessment | Risk Control Strategies <small>(Recommended for Purchase / Buyer / User)</small> |
|---|----------------------------------|-------------------|---|
| A | ENTANGLEMENT CRUSHING | HIGH | Eliminate, avoid loose clothing / Long hair etc. Heavier timber must be supported Be sure that when rising and falling planner tables hands are well away from locating, clamping and pivoting area. |
| B | CRUSHING | MEDIUM | Keep hands clear from infeed & outfeed support rollers during operation. |
| C | CUTTING, STABBING, PUNCTURING | MEDIUM | Isolate power to machine prior to any checks or maintenance. Do not open or clean inside until the machine has completely stopped. Keep hands clear of all blades and moving parts. Use a push stick where necessary. Care must be taken when handling knives. |
| D | SHEARING | MEDIUM | Make sure all guards are secured shut when machine is on. |
| F | STRIKING | MEDIUM | Make sure all guards are secured shut when machine is on. Do not stand behind timber when feeding into machine. A face mask must be worn at all times. |
| H | ELECTRICAL | MEDIUM | Ensure to use correct feed rates for material. All electrical enclosures should only be opened with a tool that is not to be kept with the machine. |
| O | OTHER HAZARDS, NOISE, DUST. | LOW | Machine should be installed & checked by a Licensed Electrician. Wear hearing protection as required. Must be connected to dust extraction |
| Plant Safety Program to be read in conjunction with manufactures instructions | | | |



www.machineryhouse.com.au



www.machineryhouse.co.nz

Authorised and signed by:

Safety officer:

Manager:

Revised Date: 29th June 2018