

Forklift Jib Attachment – Hook & Bow Shackle Installation Guide

Installation Instructions

1. Remove the 3.2T safety bow shackle and 2T swivel hook from the wooden crate.
 2. Position the forklift jib attachment so the centre lifting eye is free and easily accessible.
 3. Remove the split pin and hex nut from the bow shackle pin. Slide the pin out completely.
 4. Position the bow shackle body between the slotted mounting hole on the forklift jib. Align the holes and slide the shackle pin through the fabricated hole.
- WARNING:** Do NOT attach the bow shackle or hook to the ring that has the chain and connector attached. This ring is for the safety chain only.
5. Reinstall the hex nut onto the threaded end of the pin. Insert the split pin into the designated hole. **IMPORTANT:** Open (spread) the split pin fully so it is securely locked in place.
 6. Ensure the assembly is safe and secure.

