

HOW TO RESET A EASSON DISPLAY

When a Easson display is not performing naturally the following procedure should be undertaken to reset the system. To do this the following steps should be done.

1. Switch of the display unit and then switch on the unit and at the same time as the word “Easson” appears on the right hand display area, press “8”.

(Fig.1)



(Fig.1)



(Fig.2)

The display will then run through a series of symbols and “888888”. The system will reset and a series of tests will take place, checking the system. This will continue to run through its cycle and will not stop. After 1 minute switch the display off and then switch the unit on again. Check to see if the problem has been eliminated.(Fig.2)

If the problem continues contact your dealer