







PARTS LIST

Item	Part No.	Description	Q'ty
1	31503031	Slotted Insert	3
2	31503022	Washer	3
3	31503032	Housing	3
4	31503020	Washer	3
5	DJ250B04001	Door Lower	1
6	31503033	Housing with Nut	3
7	31503030	Tongue	3
8	GB862.2-87 6	Ext.Lock Washer 6	3
9	GB5783-86 M6x10	Hex.Hd.Bolt M6x10	5
10	DJ250B03001	Door Upper	1
11	DJ250A05001	Saw Blade	1
12	GB894.1-86 10	Ring Retaining	2
13	GB/T276-94 6000-2Z	Ball Bearing	4
14	DJ250A03005	Upper Wheel	1
15	DJ250A03005-1	Balance Collar	fit
16	DJ250A04009	Band Saw Tyre	2
17	DJ250A03004A	Bearing Bolt Upper	1
18	GB896-86	"E"Rings	2
19	DJ250A03007	Pin Guide	1
20	DJ250A03003A	Seat Bearing Bolt Upper	1
21	GB6177-86 M6	Hex.Hd.Flange Nut	8
22	DJ250A03002A	Guide Plate Assembly	1
23	GB819-85 M4x12	Cross Countersunk HD.Screw	2
24	KJD20	Magnetic Switch	1
25	DJ25005004B	Switch Plate	1
26	GB862.2-87 4	Ext.Lock Washer	2
27	GB823-88 M4x6	Cross Pan.Hd.Screw	2
28	DJ250A03010	Blade Tensioner	1
29	DJ250B01000	Band Saw Frame	1
30	DJ250A05002	Lamello Plug Black	1
31	DJ250A03008	Adjust Handle	2
32	GB6172-86 M8	Hex.Hd.Thin Nut	4
33	DJ250A03006	Thread Bolt	1
34	GB97.1-85 6	Washer	8
35	GB5783-86 M6x12	Hex.Hd.Bolt	9
36	GB5783-86 M8x45	Hex.Hd.Bolt	1
37	31503007	Wing knob	1
38	GB97.1-85 8	Washer	10
39	GB97.1-85 10	Washer	1
40	DJ250A03009	Nut	1
41	DJ250A03011	Shaft	1
42	GB/T1792 A16	Butterfly Spring	18

PARTS LIST

Item	Part No.	Description	Q'ty
43	GB6177-86 M8	Hex.Hd.Flange Nut	1
44	DJ250A04014	Spacer Bushing	1
45	31504015	Brush Strip	1
46	GB14-88 M8x70	Cup Square Neck Bolt	1
47	GB889-86 M6	Hx.Hd.Lock Nut	2
48	DJ25004011	Blade Guard	1
49	DJ250A02002	Blade Trunnion Lower	1
50	GB96-85 6	Washer	1
51	GB80-85 M6x12	Int.Hd.Screw	3
52	DJ250A04002A	Roller Guide	1
53	31504003	Pilot Pin	2
54	DJ250A03021	Thurst Bearing Shaft	4
55	GB/T276-94 625-2Z	Bearing	4
56	31504018	Idler Wheel Shaft	1
57	GB5783-86 M6x16	Hex.Hd.Bolt	8
58	DJ25002005	Blade Fork	1
59	DJ250A02001	Table	1
60	GB14-88 M6x30	Cup Square Neck Bolt	1
61	DJ25002006A	Guide Piece	1
62	DJ250A02003	Table Trunnion Upper	1
63	DJ250A02004	Indicator	1
64	DJ250A02005	Tension knob	1
65	GB5783-86 M6x30	Hex.Hd. Bolt	1
66	GB6170-86 M6	Hex. Nut	5
67	GB5783-86 M8x12	Hex.Hd. Bolt	4
68	DJ250A02014	Rip Fence Canier Extrvsion	1
69	GB879-86 3x16	Roll Pin	1
70	DJ250A02008A-8	Partiality Piece	1
71	DJ250A02008A-6	Connet Set	1
72	DJ250B02008-1	Baffle Bracket	1
73	DJ250A02008A-2	Stuck Piece	2
74	DJ250A02008A-1	Baffle	1
75	DJ250A02008A-3	Spring	1
76	DJ250A02008A-4	Clamp Board	1
77	DJ250A02008A-5	Clamp Screw	1
78	DJ315B03024	Fastening Shaft	1
79	DJ250A03014A	Seat Guide Upper	1
80	GB846-85 ST4.2x13	Cross CS.HD Tapping Screw	2
81	DJ250A03022A	Housing Upper Guide	1
82	GB80-85 M6x8	Int.Hd.Screw	3
83	GB80-85 M6x6	Int.Hd.Screw	2
84	DJ250A03024	Slide Board	1

PARTS LIST

Item	Part No.	Description	Q'ty
85	DJ250A03012	Guide Lever	1
86	DJ315B03031-1	Cover Board	1
87	GB845-85 ST4.2x9.5	Cross Pan.Hd.Screw	4
88	DJ250A03018	Rack	1
89	DJ250A03013	Guide Piece	2
90	DJ315B03016	Adjust Knob	1
91	GB889-86 M8	Hx.Hd.Lock Nut	1
92	GB818-85 M5x10	Cross Pan. Hd.Screw	3
93	DJ250A04005	Wheel Lower	1
94	DJ25004008	Pulley lower	1
95	DJ25004010	V-Ribbed Belts	1
96	GB1096-79 5x30	Key	1
97	DJ25004004	Motor Pulley	1
98	GB14-88 M6x16	Cup Square Neck Bolt	4
99	GB6171-86 M14x1.5	Hex.Nut	1
100	GB93-87 14	Spring Washer	1
101	DJ250A04006	Bearing Bolt Upper	1
102	GB93-87 6	Spring Washer	4
103	DJ25005003-1	Plate Mounting Motor	1
104	YYL7114	Motor	1
105	DJ250A05006	Motor Cord	1
106	DJ250A5005	Power Cord	1
107	GB6172-86 M6	Hex.Hd.Thin Nut	2
108	GB5783-86 M6x20	Hex.Hd.Bolt	4
109	31505010A	relief strain	2
110	DJ250A03019	Shaft	1