



Edition : 2.0
Date: (03/26)

Instruction Manual

ADJUSTABLE LEGS HEAVY DUTY UNIVERSAL STAND UTS-3HD

Order Code: (W811)

BEFORE ASSEMBLING

Please read this instruction manual before assembly.



CAUTION

Before assembly please pay attention to the following points in priority;

Confirmation of components: Before assembling, please confirm all parts arrived and are in good order.

Site for assembly: Assemble the stand on flat, level ground or a sturdy surface capable of supporting stand during assembly. Put a drop sheet or cardboard down to protect the stand pieces from getting damaged or scratched during assembly.

Points for attention when assembling: Please wear gloves to ensure that it can be assembled safely, and use two persons to help in the assembly process.

TOOLS & ASSISTANCE NEEDED



Spanner & Socket Wrench

*Tools not included

Getting Started


Before starting the assembly ensure you have the correct tools & equipment to successfully assemble the table whilst making sure you are wearing the appropriate Safety PPE.



PARTS DIAGRAM & LIST

Please check that you have all the below parts before you assemble this product

Part No.	Description	QTY
1	Support Table	1
2	Bolt M8x20mm	24
3	Leg	4
4	Adjustable Feet	4
5	Short Connecting Plate	2
6	Long Connecting Plate	2
7	Washer	40
8	Spring Washer	40
9	Nut M8	40
10	Adjustable Leg	4
11	Bolt M8x25mm	16



NOTE – Height Adjustment Options (Refer Before Assembly)

This table can be configured to suit your preferred working height using the pre-drilled adjustable leg positions. Please review the options below before commencing assembly:

- Configuration 1** **Highest Height Setting** – Achieved by assembling the table as outlined in **STEP 1** through to **STEP 4**.
- Configuration 2** **Lowest Height Setting** – Achieved by installing the **M8 x 25mm bolts (#11)** with the **Connecting Plates (#5 & #6)** as shown below.

The adjustable legs allow the table to be set at various intermediate heights to suit your application.


Note: At the full height setting, the connecting plates (#5 & #6) may also be installed on the inside if preferred.



STEP 1

- a) Carefully turn the Support Table (#1) upside down onto a stable workbench.
- b) Position each leg (#3) inside the table support corners and loosely secure using the supplied M8 x 20mm bolts (#2), M8 nuts (#9), washers (#7) and spring washers (#8) through the pre-drilled holes.

Do not fully tighten at this stage — final tightening will be completed once all components are aligned.



STEP 2

Set the Desired Height

- a) Adjust each leg to your preferred table height, ensuring all legs are set to the same height for stability.
- b) Attach the Adjustable Legs (#10) to each leg (#3) using the supplied M8 x 25mm bolts (#11), M8 nuts (#9), washers (#7) and spring washers (#8).
- c) Insert the hardware through the pre-drilled holes and tighten securely.

Do not fully tighten at this stage — final tightening will be completed once all components are aligned.



NOTE: Please refer to Page 4 for Height Adjustment Configuration Options.

STEP 3

Attach the Short and Long Connecting Plates (#5 & #6) to the outside of the Adjustable Legs (#10) as shown. Ensure all connecting plates are aligned and set to the same height before tightening. Firmly tighten all fasteners once aligned.

“Ensure all fasteners are firmly tightened before use.”



STEP 4

Screw the Adjustable Feet (#4) into the threaded holes at the base of each Adjustable Leg (#10) as shown.

Ensure they are threaded in evenly and adjusted as required to level the table.



STEP 5

Position & Level the Table

- a) With the assistance of two people, carefully flip the table to the upright position and move it into its final location.
- b) Adjust the four Adjustable Feet (#4) as required to ensure the table is level and stable. Make sure the feet are threaded evenly.

Before use, recheck that all fasteners are secure and fully tightened.





ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

IMPORTED BY

HARE & FORBES
MACHINERYHOUSE

Australian Distributor

Hare & Forbes
Machineryhouse
Sydney - Melbourne
Adelaide - Brisbane - Perth

Ph: 1300 202 200
www.machineryhouse.com.au

MACHINERYHOUSE

New Zealand Distributor

Machineryhouse
Auckland
Christchurch

Ph: 0800 142 326
www.machineryhouse.co.nz